



ECO-WORTHY

12V 600W

PURE SINE WAVE OFF-GRID INVERTER

User Manual



CONTENTS

Inverter Safety Instruction.....1

Battery Safety Instruction3

Product Features.....3

Panel Function Introduction.....6

Indicator Light Description.....9

Fault Code.....10

Installation Instruction.....10

Grounding Instruction.....11

DC Side Connection11

AC Side Operation.....11

Product Parameters.....11

Remote11

Support.....11

Inverter Safety Instruction

- Installation and wiring must comply with the Local and National Electric Codes (NEC) and must be done by a certified technician.
- Read all of the instructions and cautions in the manual before beginning the installation.
- There are no serviceable parts for this inverter. Do NOT disassemble or attempt to repair the inverter.
- Please confirm the rated battery voltage before installation. The inverters are suitable for 12V Battery Banks ONLY.
- Please confirm the positive and negative poles of the battery and the machine (red for positive pole, black for negative pole). Damage to the inverters due to reverse polarity is NOT covered by warranty.
- Please install the machine in a well ventilated place to avoid water inflow.
- After the inverter works continuously, the temperature of the case is high, which is a normal phenomenon.
- Make sure all connections going into and from the inverter are tight. There may be sparks when making connections, therefore, make sure there are not flammable materials or gases near installation.
- ALWAYS make sure inverter is in OFF position and disconnect all AC and DC connecting when working on any circuit associated with the inverter.
- NEVER connect the AC output of the unit directly to an Electrical Breaker Panel / Load Centre which is also fed from the utility power I generator.
- Be careful when touching bare terminals of capacitors as they may retain high lethal voltages even after power is removed.


Battery Safety Instruction

- Do NOT let the positive (+) and negative (-) terminals of the battery touch each other.
- When using sealed lead-acid, flooded, or gel batteries, the battery must be deep cycle type.
- Explosive battery gases may be present while charging. Be certain there is enough ventilation to release the gases.
- Be careful when working with large lead acid batteries. Wear eye protection and have fresh water available in case there is contact with the battery acid.
- Over-charging and excessive gas precipitation may damage the battery plates and activate material shedding on them. Too high of an equalizing charge or too long of one may cause damage.
- Please carefully review the specific requirements of the battery used in the system.

Product Features

- Pure sine wave. Clean power for safe operation of sensitive electronics
- Maximum efficiency 92%.
- Intelligent fan control: Start to work when the load is greater than 40% of the rated output power and the fan will be controlled according to the internal temperature.
- Protection function: input low voltage protection, input high voltage protection, overload protection, output short circuit protection, over temperature protection.
- Easy-to-read LED indicator display

Panel Function Introduction



1	ON/OFF	6	LED Display
2	Battery Negative	7	USB Output Port
3	Battery Positive	8	Remote Switch Connection
4	AC Output	9	Ground Terminal
5	LED Indicators	10	Cooling Fan

LED Display



Indicator Light Description

1. When the “” indicator light is on, it indicates that the battery voltage is being displayed.



2. When the “” indicator light is on, it indicates that the output power is being displayed.



3. When the “!” indicator light is on, it indicates that the fault code is being displayed.



Fault Code

Fault code	Description	Solution
1	BUS soft start failed	Restart the inverter
2	BUS voltage is too high	Restart the inverter
3	BUS voltage is too low	Restart the inverter
4	Inverter start failure	Restart the inverter and check the battery connections
5	Inverter high voltage	Restart the inverter
6	Inverter low voltage	Restart the inverter
7	Output short circuit	Check the load status and disconnect the load and restart the inverter
8	Battery over voltage	Check battery voltage to ensure it is within operating range
9	Battery low voltage	Check battery voltage to ensure it is within operating range
10	Over temperature	Check the fan status, Ensure that the air inlet and outlet of the inverter are not blocked and turn off the inverter for 10 minutes.
11	Overload	Check that the inverter load does not exceed the rated power

Installation Instructions

- Make sure the inverter is in the off position before connecting anything.
- Do not over-torque or over tighten the terminals. This could potentially damage the unit.
- Refer to the technical specifications for max wire sizes on the inverter and for the maximum amperage going through wires.
- Never install the inverter in a sealed enclosure with flooded batteries. Gas can accumulate and there is a risk of explosion.
- Please install the inverter in a well ventilated place to avoid water inflow.
- Do not install the inverter in the same compartment as the battery bank for it could serve as a potential fire hazard.
- Limiting electromagnetic interference (EMI)- ensure the inverter is firmly grounded to a building, vehicle, or earth grounded. Keep the inverter away from EMI receptors such as TVs, radios, and other audio/visual electronics to prevent damage/interferencetotheequipment.
- The inverter should never be mounted vertically on a vertical surface since it would present a hazard for the fan opening which is crucial for cooling the inverter.

Grounding Instructions

Pure Sine Wave inverters come equipped with a grounding lug to appropriately ground to earth or to another designated ground (for example, the metal frame of an RV). The connections to ground must be tight and against bare metal. Whether using the inverter in a mobile application, such as an RV, or in a building, grounding is highly recommended. The recommended wire size for grounding is 10 AWG insulated copper strand wire.

For more information regarding grounding, users and/or installers must consult with the Local and National Electric Codes (NEC) for more specific grounding regulations and suggestions as they can change per scenario.

DC Side Connection

1. Turn off the inverter.
2. Unscrew the battery terminals and connect to the battery using battery connection cables. Then tighten the terminals.

NOTE:

- The Pure sine Wave Inverters are suitable for 12V battery bank systems ONLY. Not following the minimum DC requirement will cause irreversible damage to the unit.
- Be careful of the positive and negative poles. Reversing the poles might cause permanent damage to the inverter. It will surely blow the internal fuse.
- Damages to the inverters due to reverse polarity is NOT covered by warranty.
- The input terminals of the inverters have large capacitors connected to them. Once a positive and negative wire are connected to the terminals, it will complete the circuit, and commence drawing a heavy current momentarily. As a result, there may be a sparking occurring even if the inverter is in the off position. To minimize sparking, it is recommended that the user have the appropriate size wire feeding into the inverters and/or install an external fuse leading into the inverter.

AC Side Connection

1. Connect electronic devices to electrical socket on the inverter. Then turn on the inverter.
2. When finish using the electronic devices, switch the devices off FIRST before turning off the inverter.

NOTE:

- Avoid switching on the inverter with the load (electronic devices) already switched on. This may trigger an overload since some electronic devices have an initial high power surge to start.
- When switching off the inverter, turn off the electronic devices first. Even though the inverter is off, the capacitors will still have a charge, so the DC and AC terminals must be disconnected when altering the circuitry.

Product Parameters

Model		ECO600W
Input	Rated Input Voltage	12V
	Rated Current	56A
	Maximum Efficiency	92%
	Battery Type	Lead acid / Lithium battery
AC Output	Rated Power	600W
	AC Voltage	220V / 110V
	Frequency	50Hz / 60Hz
	Wave From	PURE SINE WAVE
Input Protection	Bat Low Voltage Alarm	10.5V $\pm$ 0.5V
	Bat Low Voltage Recovery	11.0V $\pm$ 0.5V
	Bat Low Voltage Shutdown	10.0V $\pm$ 0.5V
	Bat High Voltage Alarm	15.0V $\pm$ 0.5V
	Bat High Voltage Alarm Recovery	14.5V $\pm$ 0.5V
	Bat High Voltage Shutdown	15.5 $\pm$ 0.5V
Output Protection	Output Short Circuit Protection	After the fault is eliminated, it can be rebooted
	Overload Protection	110% $\leq$ Load < 125%, 1 minute shutdown ; 125% $\leq$ Load < 150%, 30s shutdown ; 150% $\leq$ Load, shut down immediately.
	Over Temperature Protection	Heat dissipation temperature > 90℃ , over temperature protection
Operating Enviroment	Operating Temperature	0-40℃
	Humidity	0-80%
Other	Dimension	305*172*75mm
	Remote Control Switch Interface	Standard configuration
	USB	5V 2A

REMOTE



List Dimensions	2.9x2.3x0.9 in (73x58.7x23.8 mm)
Thickness	0.08 in (2.0 mm)
Wire Length	Approx 19.8ft

Support

If you met technical problems and cannot find a solution in this manual, please contact **ECO-WORTHY** for further assistance

Contact number:

US 1-866-939-8222

UK +44 20 7570 0328

Email: customer.service@eco-worthy.com

ECO-WORTHY reserves the right to change the contents of this manual without notice