

Model mode No: 0841

Functional

In normal display mode shows: week- hour -minute - second

Modes change: tap S3 button

Backlight tap 'S1' button

User selectable 12/24-hour format



Modes of watch

In normal display modes: tap S3 → chronograph mode → alarm setting mode → time setting mode

Chronograph functions

In normal display mode: tap S3 once → enter chronograph mode → tap S1 to start → tap S1 to stop

tap S3 to exit ← tap S1 to stop ← tap S2 to read time ↔ tap S2 to lap time ← tap S2 to reset

Set up to alarms

Hours: In normal display Mode, tap S3 twice and "the hours" will flashing

Tap S1 to reach the correct hour for your alarm. Pay attention to AM/PM

Minutes: Tap S2 and the minutes will flash. Tap S1 to reach the correct minutes.

Tap S3 to save / exit.

Set time & date

In normal display Mode, tap S3 three times to enter setting mode and "the seconds" will flashing.

Minutes: Tap S2 and the minutes will flash. Tap S1 to reach the correct minutes

Hours: Tap S2 and the hour will flash. Tap S1 to reach the correct hour. (Pay attention to AM/PM, "H" is 24 hour format)

Date: Tap S2 and the date will flash. Tap S1 to reach the current date

Months: Tap S2 and the number of the month will flash. Tap S1 to advance to the number of the current month (1=January, 2=February ...)

Day of Week: Tap S2 and the day of the week will flash. Tap S1 to advance to the current day (MO=Monday, TU=Tuesday ...)

Tap S3 to exit. Congratulations! Your watch is now set.

Alarm ON/OFF

In normal display Mode, hold tap S1 and S2 be shows "alarm" on of alarm, same as action, if the "alarm" be disappiars, it's off of alarm.

Chime of every hour ON/OFF

In normal display hold S2 and then tap S3 be show all icon of week is ON chime, same as action, if the week's icon be disappears, it's OFF of chime.

Press S4 Clock adjustment