


3-phase String Inverters-FAQ

Instructions for string inverter feed-in settings

Applicable to: 3-phase string inverters

The following parameters can be set in the advanced setting interface if the customer has a feed-in limitation requirement on site. As shown in the figure below.



1. Setting method of zero feed-in:
 - 1.1 Feed-in Limitation is enabled.
 - 1.2 Feed-in Limitation Value is set to 0 (0 kW feed-in).

2. Setting method of feed-in limitation:
 - 2.1 The Feed-in Limitation function is enabled.
 - 2.2 Feed-in Limitation Value is set according to actual requirements.

3. When there is no feedback from network:

The Feed-in Limitation function is turned off.

For further information, please download the user manual [here](#).

This manual is intended for professional technicians who are responsible for installation, operation, maintenance and troubleshooting of inverters, and users who need to check inverter parameters. The inverter must only be installed by professional technicians.

The professional technician is required to meet the following requirements:

- Know electronic, electrical wiring and mechanical expertise, and be familiar with electrical and mechanical schematics.
- Have received professional training related to the installation, commissioning and troubleshooting of electrical equipment.
- Be able to quickly respond to hazards or emergencies that occur during installation, commissioning and troubleshooting.
- Be familiar with local standards and relevant safety regulations of electrical systems.
- Read this manual thoroughly and understand the safety instructions related to operations.