Ver 1.0 2024/07

MWE Gold V2 1050/1250
User Guide

Safety Instructions

- Do not open the power supply unit as this can lead to serious injury or death.
- Do not insert objects into spinning fan. This will damage the power supply unit and can lead to injuries.
- Do not use excessive force when attaching the power connectors to the power supply unit. When correct connectors are used, excessive force is not need to install them.
- Keep power supply unit in dry environments away from humidity. If the power supply unit gets wet, immediately remove the AC power plug from the wall and the power supply unit. For your own safety, it is recommended that you do not use the power supply unit again after getting it wet.
- Avoid using low quality extension cables for the power supply side connectors as this can cause the cables to melt and even lead to fire.
- This power supply unit has been tested for PC usage only. We cannot guarantee operation or safety performance when used for other applications.

Installing the Power Supply Unit

1. Make sure the main power switch is turned off before installing the power supply unit.
2. Secure the power supply unit within the PC case enclosure with 3 or 4 screws for grounding and stability purposes.
3. Connect the power connectors according to the motherboard, graphics card, and other device user guides that will be used in the system.
4. Connect the AC power connector.
5. Switch on the power switch.

Troubleshooting

If your system does not turn on after installing the power supply, please follow the troubleshooting guide as listed below:

1. Make sure the AC power cord is correctly and firmly connected on both sides.
2. Make sure the power switch is turned on.
3. Make sure the main power connector and +12V power connectors are correctly connected to the motherboard.
4. If the power supply does not function properly, please contact our customer support immediately.

Warranty

Cooler Master guarantees this device to be free of defects in material and workmanship and provide a minimum 10-year hassle-free limited warranty for the power supply on the date of purchase. Please register on our official website to activate your limited warranty. This product was designed and intended for computer usage only. Using this device for other applications will void the warranty. If you are not familiar with computer hardware installation, please ask a professional for assistance.
This warranty only applies to the power supply unit and does not include accessories or connected components.
This warranty only applies to damage caused by normal use and is void if it is determined that the device was damaged because of abuse, alteration, misuse, negligence, incorrect voltage supply, air/water pollution, accidents, or natural disasters.
Please use the included power cables. Do NOT mix cables from different series with different units. If the power supply or other equipment is damaged due to not using the original cable, the warranty will be void and we will not provide warranty services.
In the event of any defects within the warranty period, please return product to the dealer or retailer from whom you purchased for a replacement/repair.
Please contact our customer service team for any technical or product related questions.

Limited Warranty Period: http://www.coolermaster.com/service/warranty.html
Customer Support: https://account.coolermaster.com

Pin Layout Connectors

Pin-Layout-Anschlüsse / Connecteurs de disposition des broches / Connettori layout pin / Conectores de disposición de pines / Pin-indelingen stik / Pin-Layout-Anschlüsse / Συνδετήρες διάταξης ακίδων / Distribución de patillas - Conectores / Agencement de broches de connecteurs / Pistokeliittimen asettelma / Konektori za raspored igli
Curšlokzet-ernitkezbi-kioustzuk / Konektor Tata Letak Pin / Connettori, layout pin / ピンレイアウトコネクタ / 핀 레이아웃 커넥터 / Pinbezetting van connectors / Kontaktenes pinnefordeling / Złącza układu styków / Conectores de pinos / Размещение штырьевых разъемов / Pin Layout kontakter / Pin konnektor / Pin Yerleşim Konektörleri / موصلات تخطيط الدبوس

Main Power Connector

Pin1 Pin13

Pin	Description	Pin	Description
1	+3.3V	13	+3.3V
			+3.3V
2	+3.3V	14	-12V
3	COM	15	COM
4	+5V	16	PS-ON
5	COM	17	COM
6	+5V	18	COM
7	COM	19	COM
8	+5V_G	20	--------
9	+5V_	21	+5V
10	+12V	22	+5V
11	+12V	23	+5V
12	+3.3V	24	COM

+12V Power connector

Pin1 Pin5

Pin	Description
1	COM
2	COM
3	COM
4	COM

4+4Pin

Pin	Description
5	+12V
6	+12V
7	+12V
8	+12V

8Pin

PCIe Power connector

Pin1 Pin5

Pin	Description
1	+12V
2	+12V
3	+12V
4	COM

Pin	Description
5	COM
6	COM
7	COM
8	COM

Serial ATA Power Connector

Pin	Description
1	+3.3V
2	COM
3	+5V
4	COM
5	+12V

Peripheral Connector

Pin	Description
1	+12V
2	COM
3	COM
4	+5V

12VHPWR / 12V-2x6 Power Connector

Pin1 Pin7

S1 S2 S3 S4

Pin	Description
1	+12V
2	+12V
3	+12V
4	+12V
5	+12V
6	+12V
S1	RESERVED
S2	RESERVED

Pin	Description
7	GND
8	GND
9	GND
10	GND
11	GND
12	GND
S3	SENSE 0
S4	SENSE 1

Sense 0	Sense 1	Support Power
GND	GND	600W
OPEN	GND	450W
GND	OPEN	300W
OPEN	OPEN	150W

Company Information

Informace o společnosti / Firmaoplysninger / Unternehmensinformationen / Στοιχεία εταιρείας / Información sobre la empresa/ Informations de l'entreprise/ Yhtiön tiedot / Informacije o tvrtci / Vállalat információ / Informasi perusahaan / Informazioni sull'azienda / 会社情報 / 회사 정보 / Bedrijfsinformatie / Selskapsinformasjon/ Informacje o firmie / Informação da empresa / Информация о компании / Företagsinformation / Informacije o kompaniji / Şirket bilgileri / اطلاعات شرکت

Europe - Cooler Master Europe B.V.
Lodewijkstraat 1b, 5652AC Eindhoven, The Netherlands
Tel: +31-(0)40-702-0900

North America – CMI USA, Inc.
1 N Indian Hill Blvd Suite 200,
Claremont, CA 91711, USA
Tel: +1-888-624-5099

China – Cooler Master China
Room 112, Building 9, No. 327, Songjin Road, Jinshanwei Town, Jinshan Dist., Shanghai City, China
Tel: +86-21-51872177

For Australia only:

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.
[Asia Pacific - Cooler Master Technology Inc. 7F., No. 398, Xinhu 1st Rd., Neihu Dist., Taipei City 114065]
Telephone: +886-2-2225-3517 [standard international call charges apply.]

تعليمات السلامة

- لا تفتح وحدة إمداد الطاقة لأن ذلك قد يؤدي إلى حدوث إصابات أو ربما يؤدي إلى موت محقق.
- لا تدخل أي شيء في أجزاء المراوح الدائرة. سيلحق ذلك وحدة إمداد الطاقة أو قد يؤدي إلى حدوث إصابات.
- لا تستخدم أي قوة مفرطة عند تثبيت موصلات الطاقة. فعند اختيار الموصلات المناسبة لن يتطلب الأمر أي ضبط موفر الطاقة في بيئات جافة بعيداً عن الرطوبة. في حال حدوث بلل لموفر الطاقة، انزع القابس من مصدر الطاقة على الفور، ثم انزع الموفر. هذا من أجل سلامتك، فلن تنتفي استخدام موفر الطاقة مجدداً بعد ذلك.
- يمكن تجنب استخدام كابلات التمديد ذات الجودة المنخفضة لأن ذلك قد يسبب انصهار الكابل أو نشوب حريق
- تم اختبار وحدة إمداد الطاقة تلك لاستخدام الكمبيوتر الشخصي

Инструкции за безопасност

- Не отваряйте електрозахранващия блок, тъй като това може да доведе до сериозни или дори до смъртни случаи.
- Не вкарвайте предмети във въртящ се вентилатор. Това ще повреди електрозахранващия блок или може да доведе до наранявания.
- Не използвайте нежовка грубa сила при свързване на конекторите за захранването. Когато е избран правилният конектор, не би трябвало да е необходимо да използвате груба сила.
- Съхранявайте захранващия блок в суха среда, далеч от влажност. В случай, че електрозахранващия блок се намокри, дръжте издръпайте захранващия щепсел, ако е необходимо. За ваша собствена безопасност е да избягвате да използвате отново електрозахранващия блок.
- Опитайте се да избегнете използването на удължаващи кабели за захранващите конектори, това може да причини стопяване на кабела или дори да доведе до пожар.
- Този електрозахранващ блок е изпитан за използване на настолен компютър. Ние не можем да гарантираме безопасност или правилна работа при използване за други приложения.

Инструкции за употреба

Pokyny k použití

Brugervejledning

Käyttöopas

Guide d'utilisation

Bedienungsanleitung

Οδηγός χρήσης

Használati útmutató

Panduan pengguna

Guida per l'utente

ユーザーガイド

사용 설명서

Brukerveiledning

Instrukcja obsługi

Manual do utilizador

Руководство за потребителя

Guía del usuario

Användarhandbok

Kullanıcı kılavuzu

Priručnik za korisnika

Uputstvo za korisnika

Instrucciones de seguridad

Säkerhetsanvisningar

Güvenlik Talimatları

Sigurnosne upute

Sikkerhedsanvisninger

Turvaohjeet

Instructions de sécurité

Sicherheitsanweisungen

Sigurnosna uputa

Sikkerhetsinstruksjoner

Οδηγίες ασφαλείας

Biztonsági utasítások

Petunjuk Keselamatan

Istruzioni di sicurezza

安全上の注意

안전 지침

Sikkerhetsinstruksjoner

Instrukcje dotyczące bezpieczeństwa

Instruções de segurança

Указания по безопасности

Güvenlik Talimatları

Sigurnosna uputa

Sikkerhetsinstruksjoner

Οδηγίες ασφαλείας

Biztonsági utasítások

Petunjuk Keselamatan

Istruzioni di sicurezza

安全上の注意

안전 지침

Sikkerhetsinstruksjoner

Instrukcje dotyczące bezpieczeństwa

Instruções de segurança

Указания по безопасности