



# MARATHON WINDSCHILD

Marathon windshield | Pare-brise Marathon | Parabrezza Marathon | Cúpula Marathon

Art.-Nr: 14151-00x

## LEGENDE/KEY/FILE LÉGENDE

-  **Anbau Tipp**  
Fitting tip  
Astuce de montage
-  **Achtung**  
Attention  
Attention
-  **Vergrößerung**  
Magnification  
Grossissement
-  **Montagepaste**  
Fitting lubricant  
Lubrifiant de montage

-  **Schraube**  
Screw  
Vis
-  **Schraubensicherung**  
Thread locking fluid  
Freiniflets
-  **Drehmoment**  
Torque  
Torque
-  **Reiniger**  
Cleaner  
Nettoyant



Management System  
Verifiziert gemäß  
genehmigungs-  
relevanter  
Anforderungen



www.tuv.com  
ID 9000012000



0307206



3



4



**Bitte alle Anbauteile lose am Fahrzeug vormontieren und ausrichten. Erst danach die Schrauben nach Vorgabe anziehen.**

*First, tighten all screws only loosely. After mounting all parts, the screws should be tightened to the torque specified. Tout d'abord, ne serrez pas toutes les vis sans les serrer. Après avoir monté toutes les pièces, les vis doivent être serrées au couple spécifié.*

2