

PLASTIC RAIN GAUGE

WATER MAGNIFIES MEASUREMENTS
BY 35% FOR EASY READING



To Measure Rainfall:


For accurate readings, place rain gauge in open area away from buildings, trees, or other obstructions.

Side Mount:


Mount rain gauge onto level surface. Anchor with 2-inch screws (not included).

Ground Mount:

Push rain gauge into level ground.



SIDE MOUNT



GROUND MOUNT

PRODUCT FACTS:

MEASUREMENT RANGES

Rainfall: 0 to 5 inches

Rain gauge cannot be used in below-freezing temperatures

1
YEAR

LIMITED 1-YEAR WARRANTY

Register your product at:
www.acurite.com/product-registration

AcuRite uses patented technology.
Visit www.acurite.com/patents for details.
REV0624 AcuRite is a registered trademark of
Chaney Instrument Co. 965 Wells St. Lake Geneva, WI 53147



Made in China • Hecho en China | www.AcuRite.com/support



DO NOT ALLOW WATER TO FREEZE IN TUBE. ICE MAY CRACK TUBE.

