



1080P ProStream HD Webcam

User Manual



Model: AWC205-B

Thank you for purchasing an Amcrest Webcam!

We wanted to personally reach out and thank you for purchasing from our Amazon store. Selling on Amazon is what we do to support our family, and product reviews are the lifeblood of our business. It would mean the world to us if you could take one minute of your time to help share the love by leaving us an honest review using the link below:

www.amazon.com/ryp

Thank you again for being one of our amazing customers!

Sincerely,

Amcrest Team

Product Overview

Thank you for purchasing an Amcrest Webcam!

This guide is designed to help you setup and better use your Amcrest webcam. If you have questions before you start or just want to learn more about Amcrest, please visit us at: amcrest.com





Setting Up Your Webcam

1. Placing Your Webcam

The webcam has an adjustable clip base which allows the device to be secured to a monitor, or desktop, or tripod.


Placement on a Monitor

- Grasp the webcam, as displayed in the image below, and open the clip base.
- Place the opened clip base onto the monitor making sure the foot of the clip base is flush with the back of the monitor.




Placement on a Flat Surface

Place the camera on a flat surface and use the adjustable clip base to move and adjust the camera according to your preference.



Placement on a Tripod


Place the 1/4"20 tripod screw on the bottom of the adjustable clip base to the male end of a tripod and twist the base allowing it to be secured to the tripod (sold separately).



Connecting the Webcam

The webcam is compatible with Windows, Linux, and Mac operating systems. For more information on connecting your webcam, please refer to the information below.

- 1) Connect the webcam's USB cable to a USB port on your computer. The status indicator on the camera will illuminate indicating the webcam is properly connected.
- 2) Allow any drivers or other software to load and open a video chat or recording software of your choice to open the camera.



Amcrest NetDesk

Amcrest NetDesk is a video communications tool, provided by Amcrest, which can be used along with your Amcrest webcam. For more information on Amcrest NetDesk, please visit:

<https://www.netdesk.com/>

How do I Improve Audio Quality?

If you are experiencing issues with audio on your webcam, the audio quality can be optimized using third party software such as Equalizer APO. The Equalizer APO software can be optimized as well using the Peace GUI equalizer extension.

For more information on how to improve microphone quality, visit: <https://amcrest.com/audio>

Technical Specifications

Model	AWC205-B
Image Sensor	1/3" CMOS Imaging Sensor
Video Resolution	1920 * 1080 / 1280*720 / 640 * 480
Lens	3.6mm
Angle of View	70°
Privacy Cover	Supported
Tripod Attachment	1/4" diameter, 20 threads per inch
Microphone	Built-in high sensitivity microphone
USB	USB 2.0 Plug and Play
Compatibility	Windows XP/Win7 /Win 8/Win10, Mac, etc.
Dimensions	3.54" x 3.34" x 0.94"
Cable Length	5.90ft (1.8m)



www.amcrest.com

© 2020 Amcrest. All rights reserved. Amcrest, the Amcrest logo, and other Amcrest marks are owned by Amcrest and may be registered. Microsoft, Windows, and the Windows logo are trademarks of the Microsoft group of companies. All other trademarks are the property of their respective owners. Amcrest assumes no responsibility for any errors that may appear in this manual. Information contained herein is subject to change without notice.

RECE