


Part No. 31-AJSGH100-4R1

100-FT | KINK-PROOF | PUNCTURE-PROOF
**STAINLESS STEEL
GARDEN HOSE**

Manguera de jardín de acero inoxidable de 100 pies, libre de torceduras y a prueba de perforaciones
Beyou d'arrosage imperforable en acier inoxydable | Anti-pli | 3D m

Model/Modelo/Modèle AJSGH100





Assembling Hose to Faucet

1. Remove the stainless steel garden hose from the package and completely unwind your garden hose.
2. Before using the garden hose, make sure the rubber washers (included) are firmly set inside the two connectors.
3. Attach any spray nozzle or irrigation accessory to the outlet of the garden hose.
4. Attach the garden hose inlet to the water supply of your home.
5. Turn on the tap from your home's water supply to the garden hose.

Storing Your Garden Hose


You can store your stainless steel garden hose on just about any common hose reel or simply coil it next to your faucet. To extend the life of your hose, store out of direct sunlight.

NOTE: When you are finished watering with your stainless steel hose, release the water pressure before storing. To extend the life of your hose, shut off your water and remove or open the nozzle.

WARNING!

- Stainless steel garden hose is NOT intended for drinking/potable water use. Do NOT drink from any garden hose. Wash hands after use.
- The water in ANY garden hose may become contaminated and cause serious health effects.
- Strangulation hazard. Hose wrapped around neck may cause serious injury or death.
- Keep out of reach of children and pets.
- For general OUTDOOR USE ONLY in applications under 80 psi.
- NOT for commercial applications, in hot water applications, or high pressure applications (such as pressure washer). Improper use may result in serious personal injury and/or damage or destroy the hose.
- DO NOT leave this garden hose unattended when it is in use or under pressure.
- NOT a toy.

Sin BPA, sin plomo, sin ftalatos



Conexión de manguera a grifo

1. Retire la manguera de jardín de acero inoxidable del paquete y desenróllela por completo.
2. Antes de usar la manguera de jardín, asegúrese de que las arandelas de goma (incluidas) estén firmemente colocadas dentro de los dos conectores.
3. Conecte cualquier boquilla de rociado o accesorio de riego a la salida de la manguera de jardín.
4. Conecte la entrada de la manguera de jardín al suministro de agua de su hogar.
5. Abra la llave del suministro de agua y riegue con su manguera de jardín.

Almacenamiento de su manguera de jardín

Usted puede almacenar su manguera de jardín de acero inoxidable en casi cualquier carrete de manguera, o simplemente enrollarla junto al grifo. Para prolongar el ciclo de vida útil de su manguera, guárdela lejos de la luz directa del sol.

NOTA: luego de regar con su manguera de acero inoxidable para jardín y antes de almacenarla, libere la presión de agua. Para prolongar el ciclo de vida útil de su manguera, cierre la llave de agua y retire o abra la boquilla.

¡ADVERTENCIA!

- La manguera de jardín de acero inoxidable NO ESTÁ DESTINADA para ser usada con agua potable. NO BEBA AGUA de ninguna manguera de jardín. Lávese las manos luego de usarla.
- El agua en CUALQUIER MANGUERA DE JARDÍN puede estar contaminada y causar graves daños a la salud.
- Peligro de estrangulamiento: una manguera enrollada alrededor del cuello puede causar lesiones severas o la muerte.
- Manténgala alejada de niños y mascotas.
- Solo para uso EN EXTERIORES, bajo 80 PSI.
- No la use en aplicaciones comerciales, con agua caliente, o con alta presión de agua (como por ejemplo con una hidrolavadora). Un uso incorrecto puede causar graves lesiones personales y/o daños o destrucción de la manguera.
- NO DEJE esta manguera de jardín sin atender cuando esté usada o bajo presión.
- ESTA MANGUERA DE JARDÍN NO ES UN JUGUETE.