



**12,000mAh Portable Jump Starter  
CTJMPST12KA  
Quick Start Guide**



**Table of Contents**

Overview .....	2
Operation.....	2
Specifications.....	4
In the Box.....	4



# Overview



1	Power switch
2	Power indicator lights
3	Master ON/OFF switch
4	DC 12V output
5	USB output 5V/2.1A
6	EC5 output for jump starting
7	LED lights
8	15V/1A input

# Operation

## Indicator Lights

Press the power switch lightly to check the remaining battery capacity.

Indicator Lights	4 Off	1 Solid ON	2 Solid ON	3 Solid ON	4 Solid ON
Capacity	0%	25%	50%	75%	100%

While the jump starter is being charged, the indicator lights will flash one by one until it is at full charge. All 4 indicator lights will stay on when the jump starter is fully charged.

## How to Turn on the LED Light

Press and hold the Power button for 3 seconds to turn on the LED light. Once the LED light is turned on, double pressing the power button will cycle through additional modes.

(Solid light → Strobe light → SOS flashing → OFF)

## Charging the Jump Starter


1. Plug the AC adapter to the AC electrical socket.
2. Insert the adapter plug into the DC input port of the device or insert the car charger into the car charger port.
3. Insert the other end of the car charger into the DC input port of the device.

## Jump Start a 12V Car


1. Make sure the battery capacity of the jump starter is above 50%. (at least two indicator lights ON)
2. Connect the red battery clip to the battery's positive pole (+) and black clip to the battery's negative pole (-).




3. Insert the battery clips plug into the car jump port of the portable jump starter.



4. Start the car.
5. Disconnect the battery clip plug from the car jump port of the portable jump starter.



6. Disconnect the red and black battery clip from the battery's positive and negative poles.



Warning: Do not touch the red and black clamps together or connect both to the same piece of metal to prevent physical injury and damage to the vehicle. Do not use the jump start cable for any other purpose. **Always keep away from children.**

## Charging Mobile Phone or other USB devices

1. Choose the appropriate charging cable for your device from the provided Phone/Micro USB/Mini USB cable.
2. Plug the USB port of the charging cable into the USB 5V output port of the device.
3. Connect the other end of the cable to your device.
4. Press the power switch and charging begins.

**Note:** The USB indicator light will stay on when charging, if it doesn't charge the device for more than 3 seconds, the USB indicator light will automatically turn off.

**Warning:** Using other cables may damage your device, or the jump starter.

## Specifications

Weight	400g
Output	5V/2.1A, 12V/2A
Dimensions	170x80x38mm
Start current	300A
Input	DC 15V/1A
Peak current	600A

## In the Box

### Accessories

Heavy-Duty Jump Start Cables	
DC Adapter Charger	
AC to DC Adapter Charger	
Phone/Micro USB/Mini USB	
Vehicle Charging Adapter	

User manual is subject to change without notice. For the latest version of your user manual, please visit <https://www.kogan.com/usermanuals/>