




CDR 875 G

## CONTROLS & CONNECTIONS

## QUICK START GUIDE



# drive HD™

Record your ride



The functions of Buttons 1-4 are indicated by the icon directly above each button and change depending on the state of the unit.

## INSTALLATION

1

### MOUNT

Screw the included suction cup into the mount. Slide the mount into the camera and press the lever to secure the unit to your vehicle's windshield.

Plug the GPS cable from the mount into the GPS port on the dash cam.



2

### POWER

Plug the unit into your vehicle's cigarette lighter plug.

3

### DRIVE!

When power is applied the unit will automatically turn on and start recording.

Press to stop recording and to start again.

Pressing at any time will capture a still photo.

Press to create an **Emergency Recording**.


Emergency Recordings will not be overwritten by Continuous Loop Recording.

Press to turn the screen **OFF**. The dash cam will continue recording. Press any button to turn the screen back **ON**.



## iRadar® APP CONNECTION

The CDR 875 G uses a Bluetooth® Smart connection to the **Cobra iRadar®** smartphone app. Smartphone integration allows for displaying iRadar driver awareness alerts including:



Download the app from the App Store or Google Play.



### For iPhone® 4s and later with Bluetooth® Smart:

- Power on your dash cam.
- Make sure your iPhone's Bluetooth is ON. The dash cam will **NOT APPEAR** in the iPhone's Bluetooth Settings Menu.
- Start the Cobra iRadar App. Press the **Menu** button in the upper left of the app and select **Devices**. Follow the onscreen instructions to complete the pairing and connection.
- When complete, a "connected" chime will sound and will turn white on the dash cam display.

### For Android™ Devices with Bluetooth® Smart:

- Power on your dash cam.
- Enter your Android device's Bluetooth Settings Menu.
- Scan for Devices and select **Drive HD** to pair.
- Enter the Cobra iRadar App. A "connected" chime will sound, and will turn white on the dash cam display.

## COMPUTER CONNECTION

To view videos on a computer connect the dash cam using the included cable.

Select **Connect to Computer** on the dash cam. It will mount as a drive on the computer called **DriveHD**. Movie clips and photos can be found in the DCIM folder.

Video clips are saved as .MOV files and can be played by most video players on both PC and Mac.

In order to see embedded GPS, Speed, Heading, and G-Sensor information you must view videos using Cobra's **Drive HD™ Player**.

Drive HD Player can be downloaded for free at: [www.cobra.com/dashcamsoftware](http://www.cobra.com/dashcamsoftware)

### STORAGE

An 8GB MicroSD card comes installed in this dash cam, but it supports cards up to 32GB as long as they are Class IV or higher.

**For full product manuals, firmware updates and additional language support, visit [www.cobra.com](http://www.cobra.com)**

For a list of **Bluetooth Smart Ready** devices visit: [www.bluetooth.com](http://www.bluetooth.com)



HDMI, the HDMI logo, and High-Definition Multimedia Interface are trademarks or registered trademarks of HDMI Licensing, LLC in the United States and/or other countries. The Driver Awareness Alert display feature is subject to US Patent Numbers 8,842,004, 8,970,422, 9,132,773, 9,135,818 and additional pending US Patent Applications.

©2015 Cobra Electronics Corp., Part No.: 480-1063-P, Printed in China, Version A