

HIGH GAIN WIRELESS MICROPHONE ANTENNA KIT (PART # 0A-1340-0325) HIGH GAIN PERSONAL MONITOR ANTENNA KIT (PART # 0A-1340-0326)

Component	Description	Quantity	
		0A-1340-0325	0A-1340-0326
	Telescoping Wall/Ceiling Mount	2	1
	Locking Mic Stand Clutch	2	1
	Thread Adapter	2	1
	Antenna	2	1
	50' (15 m) Coaxial Cable	2	1

1. Mount antennas to wall mounts.
 - a. Threaded end stud on the mount can be oriented vertically or horizontally.
 - b. Use the 1/4" thread side of the threaded stud and attach the thread adapter.
 - c. Attach the locking clutch to the thread adapter.
 - d. Attach the antenna to the clutch.

Notes:

- Antennas must be within 40' (12 m) of front-end audio rack.
 - Dual antennas must be at least 6' (1.8 m) apart.
 - Due to varying mounting surfaces, screws are to be provided by installer.
2. Route and connect coaxial cables to the front-end rack. Antennas already in place on the rack may need to be removed to connect the coaxial cables. Refer to documentation provided with the audio rack for antenna connector locations.
 3. Aim dual antennas toward microphone usage area, approximately 45° apart. For example:
 - Football: aim at each 30 yard line
 - Basketball: aim at each free throw line
 4. Aim personal monitor antenna toward on-stage talent usage area.