

SAFETY INSTRUCTIONS

1. Before using, read user manual.
2. Do not charge and discharge the power bank at the same time.
3. Do not expose the power bank to rain or moisture.
4. Disconnect from device when not in use.
5. Never use an extension cord or any attachment not recommended by manufacturer, otherwise this may result in a risk of fire, electric shock or injury to persons.
6. Do not operate the power bank if it has been subjected to shock or damage.
7. Do not disassemble the power bank. Incorrect reassemble may result in a risk of electric shock or fire.
8. Unplug the power bank from any devices before attempting any maintenance or cleaning.
9. The appliance is not intended for used by young children or infirm persons without supervision. Young children should be supervised to ensure that they do not play with the appliance.
10. This power bank contains a Lithium-ion polymer battery inside, do not dispose the power bank into rubbish bin. Contact your local council for disposal instructions.

PACKAGE CONTENTS

- 1 x 10,000mAh Dual USB Portable Power Bank
- 1 x Micro USB to USB-A Charging Cable
- 1 x User Manual

SPECIFICATIONS

Battery Type:	Lithium Polymer
Capacity:	10,000mAh
Input:	5V, 1.5A (USB 2.0 Micro B)
Output:	
USB Port 1:	5V, 1A (USB 2.0 Type A)
USB Port 2:	5V, 2.4A (USB 2.0 Type A)
Dimensions:	149(L) x 74(W) x 15(D)
Weight:	236g

Distributed by:
TechBrands by Electus Distribution Pty. Ltd.
320 Victoria Rd, Rydalmere, NSW 2116 Australia
Ph: 1300 738 555
Int'l: +61 2 8832 3200
Fax: 1300 738 500
www.techbrands.com
Made in China



**10,000mAh Dual USB
Portable Power Bank
with Micro USB Charging Lead
MB-3795
User Manual**

PRODUCT INFORMATION

Thank you for purchasing the Digitech 10,000mAH Dual USB Portable Power Bank. Please read through and familiarise yourself with this manual before you use the power bank.



COMPATIBLE DEVICES

The power bank can be used with multiple devices including iPad®, iPhone®, iPod®, Samsung, HTC, Android Phones and tablets, Blackberry, Kindle E-Readers, GPS devices, etc.

PLEASE NOTE

Do not place heavy objects on top of the product. Keep away from extreme temperatures and store away from dust and humidity.

OPERATING INSTRUCTIONS

1. Power On

Press the ON/OFF button, the LED indicator will light up, showing how much power is remaining in the power bank. Each light represents 25% of the capacity.

Light Indicator

Lighting Number	••••	•••	••	•
Remaining Power	100%	75%	50%	25%

2. Power Off

If the power bank is not used for 30 seconds the unit will enter into low power standby.

3. Recharging the Power Bank.

Use a Micro USB cable to charge the power bank through the USB micro socket on it. When the indicator lights up, it's charging.

4. Using Power Bank to Recharge other Devices

- There are 2 x USB-A output ports in the power bank. For power hungry devices charge using the 2.4A outlet, for other devices use the 1A outlet.
- Micro B charging cable is included, if device doesn't have Micro B connector we suggest to use the original cable provided with the device.

5. Long Term Storage

- The battery will automatically discharge when not in use. So please disconnect all cables for long term storage. Please charge the battery once every 3 months.