

0.43x High Definition Super Wide Angle Lens User Manual

1. Product Overview

This 0.43x Super Wide Angle Lens is an auxiliary lens designed to attach to your existing camera lens. It features a detachable macro section, allowing you to capture both expansive wide-angle scenes and detailed close-ups.

2. Package Contents

1. 0.43x Super Wide Angle Lens

3. Installation Guide

3.1 Check Your Camera Lens Thread Size

Look for the symbol 'Ø' followed by a number (e.g., Ø52mm, Ø58mm) printed on your camera lens. Purchase the correct size adapter ring if needed.

3.2 Attach the Wide-Angle Lens

Remove the rear cap of the wide-angle lens.

Align the threads of the wide-angle lens with your camera lens.

Gently screw the wide-angle lens onto your camera lens in a clockwise direction until it is snug. Do not over-tighten.

4. Usage Tips

For best results, shoot in bright light to minimize vignetting (dark corners).

Avoid using the built-in flash, as it may cause uneven lighting or lens flare.

The wide-angle lens exaggerates perspective; keep the camera level to avoid distortion.

Clean the lens surface with a microfiber cloth before use.

5. Safety & Maintenance

Important Warnings

Do not touch the optical glass surface with your fingers.

Keep the lens away from water, dust, and extreme temperatures.

Use only lens cleaning fluid and a microfiber cloth to clean the lens.

Remove the lens from your camera when not in use and store it in the provided pouch.