

Notes on the use and maintenance of sunglasses

1. If the lenses are loose, please check if it is caused by a loose screw. If this is the case, take a screwdriver and lightly twist it clockwise.
2. If there are stains, grease or fingerprints on the lenses, use the spectacle cloth included in the special sunglasses accessories to wipe any dust or dirt from the lenses. Never use your fingernails or chemical products to remove marks and dirt from the lenses.
3. Do not expose the lenses to liquids, electric currents or magnetic fields for long periods of time, and do not expose them to sunlight for long periods of time.
4. Do not leave the lenses in a heated room or in a place easily exposed to the sun for a long time, as they are easily discoloured or deformed by light and heat contact.

If there are fine sand particles on the lenses, please rinse them with water and dry them with a cloth or paper for glasses.

Please use both hands to put on or take off your glasses, as using one hand can easily deform the frame.

7. When your glasses are not being worn, remove them and place them in their case or place them on the table with the lenses facing upwards. Do not let the lenses touch the table, as this can easily cause wear and tear to the lenses.
8. Do not place your glasses directly with hard objects, such as keys, pens, mobile phones, etc.