

HOLMAN

PORTABLE

Retractable Hose Reel

1121H



DOWNLOAD THE
LATEST MANUAL!

User Guide

Contents

Introduction	2
Overview	3
Installation	4
Operation and Care	5
Troubleshooting	6
Spare Parts	6
Warranty Disclaimer	7

Product Dimensions (mm):

1121H 20m W:500 H:420 L:270 Weight: 8.7kg

⚠ Please read these instructions in full before proceeding with setup

Introduction

Your HOLMAN **Portable Retractable Hose Reel** uses a 12mm **HYBRID FLEX HOSE** for added strength and durability, rated to 3,000kPa and includes a **7x FUNCTION SPRAY GUN**.

For your information, please read these installation instructions before using your **Portable Retractable Hose Reel**. Please keep all instructions and refer to them when necessary.

⚠ Do not leave the tap on—turn tap off after use and release excess pressure by pressing the lever on the watering gun before retracting back into housing

Overview

- a. Housing
- b. Ground Spikes
- c. Hexagonal Coach Bolts
- d. Plugs
- e. Hybrid Flex Hose
- f. Tap-to-Reel Hose
- g. 7× Function Spray Gun
- h. Hose Connectors
- i. Universal Tap Adaptor
- j. Ball Stopper
- k. Carry Handle
- l. 360° Swivel Base



Installation

Your **Portable Retractable Hose Reel** can be set up on lawn/ground, or can be bolted to a concrete floor.

Lawn/Ground

1. Check the **TAP-TO-REEL HOSE** can reach your tap prior to inserting the **GROUND SPIKES** (maximum 2m from tap to hose reel)
2. Place the **Portable Retractable Hose Reel** on a flat area of ground. Insert the **GROUND SPIKES** [a] one at a time using a rubber mallet to help push them all the way down to secure the unit

⚠ Avoid hammering into hard ground as this could bend or damage the GROUND SPIKES

3. Check the unit is secured by the **GROUND SPIKES**, adjust them if needed
4. Connect your **TAP-TO-REEL HOSE** to your tap



Concrete Floor

1. Check the **TAP-TO-REEL HOSE** can reach your tap before proceeding (maximum 2m from tap to hose reel)
2. Place the **Portable Retractable Hose Reel** in the required position and mark the 4 holes carefully

⚠ It is very important to use the correct size drill bit, so a very secure fit is made before installing the Portable Retractable Hose Reel

3. When ready, drill all four holes, then hammer the **PLUGS** gently into your concrete floor
4. Place the **Portable Retractable Hose Reel** in position over the four **PLUGS** and screw in each **HEXAGONAL COACH BOLT** until all four have a secure hold on the base against the floor
5. Connect your **TAP-TO-REEL HOSE** to your tap

PLUG



Ø11.7mm

MASONRY DRILL



Ø10.0mm

BOLT



Ø8.0mm

Operation and Care


Extending, locking and retracting the HYBRID FLEX HOSE

- i** Pull the **HYBRID FLEX HOSE** to the desired length and stop, the hose will lock.
- i** A short tug on the **HYBRID FLEX HOSE** will unlock the hose and allow it to extend further or retract back to the unit. If you want to stop at another desired length a small tug on the **HYBRID FLEX HOSE** will lock the hose again.

⚠ When extending the **HYBRID FLEX HOSE** from its fully retracted position try to pull parallel to the ground to avoid the **BALL STOPPER [b]** catching on the **HOUSING**. If it gets caught, stop pulling and unhook the ball stopper before extending the **HYBRID FLEX HOSE**.



⚠ You will find an indication sticker [c] 1 metre before the maximum length. Do not pull the hose past this point



- i** When walking the **HYBRID FLEX HOSE** back to the **HOUSING**, turn off the tap, press the lever on the **7x FUNCTION SPRAY GUN [d]** to release the water pressure in the hose. This makes the retraction of the **HYBRID FLEX HOSE** a lot easier and prolongs the life of your **Hose Reel**.



⚠ Do not leave the water turned on with the hose under pressure when not in use

⚠ Always turn the water off and draw the water from the hose after use

⚠ Do not attempt to pull hose reel apart

⚠ Do not pull the **HYBRID FLEX HOSE** to start retraction and let go of the hose. Always guide the **HYBRID FLEX HOSE** back to the housing

Troubleshooting

Question	Answer
<p>Why is my fully extended HYBRID FLEX HOSE not retracting?</p>	<p>✓ If the HYBRID FLEX HOSE retraction wheel is stuck and the HYBRID FLEX HOSE is fully extended, the wheel still has movement past this point. Grip the HYBRID FLEX HOSE close to the guide hole and gently pull.</p> <p>The retraction wheel will give you enough movement to unlock itself before you slowly allow the auto retraction wheel to wind the HYBRID FLEX HOSE back into the unit.</p>

⚠ Do not leave the tap on—turn tap off after use and release excess pressure by pressing the lever on the watering gun before retracting back into housing

⚠ 3,000kPa burst pressure

⚠ 3°C min working temperature

⚠ Not recommended for drinking purposes

Customer Service

support@holmanindustries.com.au
www.holmanindustries.com.au

AN RWC BRAND

RWC Reliance Worldwide Corporation (Aust.) Pty. Ltd.

27-28 Chapman Place
Eagle Farm, QLD, Australia 4009

Warranty

2 Year Replacement Guarantee - Housing



Holman offers a 2 year replacement guarantee with this product.

In Australia our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

As well as your statutory rights referred to above and any other rights and remedies you have under any other laws relating to your Holman product, we also provide you with a Holman guarantee.

Holman guarantees this product against defects caused by faulty workmanship and materials for 2 years domestic use from the date of purchase. During this guarantee period Holman will replace any defective product. Packaging and instructions may not be replaced unless faulty.

In the event of a product being replaced during the guarantee period, the guarantee on the replacement product will expire 2 years from the purchase date of the original product, not 2 years from the date of replacement.

To the extent permitted by law, this Holman Replacement Guarantee excludes liability for consequential loss or any other loss or damage caused to property of persons arising from any cause whatsoever. It also excludes defects caused by the product not being used in accordance with instructions, accidental damage, misuse, or being tampered with by unauthorised persons, excludes normal wear and tear and does not cover the cost of claiming under the warranty or transporting the goods to and from the place of purchase.

Should you suspect your product may be defective and need some clarification or advice please contact us directly:

1300 716 188

support@holmanindustries.com.au

8 Year Replacement Guarantee - Hose



Holman offers an 8 year replacement guarantee with this product.

In Australia our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

As well as your statutory rights referred to above and any other rights and remedies you have under any other laws relating to your Holman product, we also provide you with a Holman guarantee.

Holman guarantees this product against defects caused by faulty workmanship and materials for 8 years domestic use from the date of purchase. During this guarantee period Holman will replace any defective product. Packaging and instructions may not be replaced unless faulty.

In the event of a product being replaced during the guarantee period, the guarantee on the replacement product will expire 8 years from the purchase date of the original product, not 8 years from the date of replacement.

To the extent permitted by law, this Holman Replacement Guarantee excludes liability for consequential loss or any other loss or damage caused to property of persons arising from any cause whatsoever. It also excludes defects caused by the product not being used in accordance with instructions, accidental damage, misuse, or being tampered with by unauthorised persons, excludes normal wear and tear and does not cover the cost of claiming under the warranty or transporting the goods to and from the place of purchase.

If you are certain your product is defective and is covered by the terms of this warranty, you will need to present your defective product and your purchase receipt as proof of purchase to the place you purchased it from, where the retailer will replace the product for you on our behalf.



Thanks for being a #SMARTGARDENER



We really appreciate having you as a customer, and would like to say thank you for choosing us.

We recommend registering your new product on our website. This will ensure we have a copy of your purchase and activate an extended warranty. Keep up to date with relevant product information and special offers available through our newsletter.

www.holmanindustries.com.au/product-registration/



HOLMAN

For the #SMARTGARDENER   

Copyright © 2024 Holman Industries