




Amplify

BT Soundbar with Subwoofer

TECHNICAL SPECIFICATIONS

Power output: 120W
 Speaker drivers: 2.25"/30W speakers * 2 + 5.25"/60W subwoofer
 Bluetooth version: 5.3v
 Bluetooth range: Up to 10m
 Connections: HDMI(ARC), OPTICAL, USB, AUX, BLUETOOTH
 Power supply: AC 100-240V
 Dimensions:
 Soundbar 800 x 95 x75mm
 Subwoofer 200 x 200 x 300mm

CONNECTIONS



- HDMI (ARC): Connect compatible devices using a HDMI cable (not provided).
- Optical In: Connect compatible devices using an optical cable (not provided).
- USB: Connect a flash drive for direct MP3/WAV playback (FAT32 format and 32GB max).
- AUX: Connect compatible devices using the 3.5mm stereo jack cable (provided).
- AC IN: Connect the AC power supply.
- ON/OFF: Turn on or turn off the device.


LED DISPLAY

- Red LED: Standby mode
- BT: Bluetooth mode
- USB: USB media mode
- AUX: Auxiliary input mode
- OPT: Optical mode
- ARC: HDMI(ARC)mode

REMOTE CONTROL & FUNCTION KEYS

Button	Function	Button	Function
	Power ON/OFF	MODE	Shifting between BT/USB/AUX/OPTICAL/HDMI(ARC)
	Mute or recover the volume	BT	Shifting into BT Mode, In BT mode, hold to enter pairing mode
TREBLE+	Increase the Treble	USB	Shifting into USB Mode
TREBLE-	Decrease the Treble	AUX	Shifting into AUX Mode
BASS+	Increase the Bass	OPT	Shifting into Optical in Mode
BASS-	Decrease the Bass	HDMI (ARC)	Shifting into HDMI(ARC) Mode
VOL+	Volume turning up	EQ	Shifting to different EQ
VOL-	Volume turning down	3D	3D Surround on/off
	Pause/Play		USB Repeat modes
	Previous track		Next track

CONTROL PANEL



- Power / Mode Button: Press once to turn on / Long press to turn off. When the speaker is turned on, press the power button once to switch input mode.
- BT: Press once to switch to Bluetooth mode / Long press to disconnect BT.
- Volume down (-) / Previous: press once to decrease volume. Long press to skip to previous track (Bluetooth/USB mode only).
- Play/Pause: Press once to play and pause.
- Volume up (+)/Forward: Press once to increase volume. Long press to skip to the next track (Bluetooth/USB mode only).

INPUT FUNCTIONS

- Power on/off:** Press the Power on/off button on the remote control or soundbar control panel to turn the soundbar on and off.
- HDMI(ARC):** Connect an HDMI ARC compatible device to the HDMI(ARC) port on the soundbar using a HDMI cable (not supplied). Select HDMI(ARC) mode either by pressing the MODE button on the remote control or the MODE button on the soundbar control panel until ARC is displayed on the LED display. Ensure HDMI ARC is selected as the TV's audio output,

then adjust the volume of the soundbar by pressing the Volume up and Volume down buttons on the remote control or soundbar control panel.

- AUX:** Connect a compatible device using the RCA to AUX cable. Select AUX mode either by pressing the MODE button on your remote control or repeatedly pressing the MODE button on the soundbar control panel until AUX is displayed on the LED display. Ensure the connected device is producing an audio signal, then adjust the volume of the soundbar using the Volume up and Volume down buttons on the remote control or soundbar control panel.
- Optical in:** Connect a compatible device to the OPTICAL input on the soundbar using a digital optical cable (not supplied). Select OPT mode either by pressing the MODE button on remote control or the MODE button on the soundbar control panel until OPT is displayed on the LED display. Ensure Optical SPDIF is selected as the TV's audio output, then adjust the volume of the soundbar by pressing the Volume up and Volume down buttons on the remote control or the soundbar control panel.
- Bluetooth:** Press the MODE button on the remote control or repeatedly pressing the MODE button on the soundbar control panel until BT is shown on the LED display. The LED display will flash to indicate that the soundbar is in Bluetooth pairing mode. Ensure that the device you wish to connect is also in pairing mode and search for "iGear Amplify" in the Bluetooth device list. The LED display on the soundbar will stop flashing and remain constant when the two devices are paired. (The soundbar will now automatically re-pair with this device when it is within distance range and in Bluetooth mode.)
- USB:** The soundbar is compatible with USB flash memory up to 32GB (Fat32 format) and supports MP3 and WAV audio files directly. Simply insert a compatible USB flash driver into the

USB port on the back of the soundbar and the unit will automatically switch to USB mode and play the first compatible track.
 USB repeat mode (also accessed via the remote control) enables random play (RAN), single track repeat (ONE), all track repeat (ALL)
 The media player also has a memory function that will recall and continue from the last-played point when a USB flash driver has been used with the soundbar is reinserted.

- Equalizer modes:** The soundbar has three equalizer default settings which are tailored to different music styles. Press the EQ button on the remote control to choose among Music mode (EQ1), Movie mode (EQ2) and News mode (Eq3).

CAUTION

- Don't expose the soundbar and the subwoofer in a high temperature, wet environment. Avoid dropping either of the units as well.
- To reduce the risk of electronic shock or fire, do not remove the cabinet cover. Please contact a professional for maintenance.
- Please do not attempt to repair the malfunction by yourself. Contact certified professionals for a proper diagnosis and repair.
- Please cut off the power right away when fragments or liquids fall into the speaker or the subwoofer. Do not re-use the equipment before a professional checks them.
- Don't install the device at the place where it may come in contact with water, moisture or other liquids.

WARRANTY

Warranty Period: 1 Year
 In case of consumer complaints:
 Customer Care: +91 93726 67193
 Email: support@igear.asia
 (Between 10am to 5pm, Mon to Fri)

For warranty support, scan the QR code

