




## 特技车使用说明书

请在使用前详细阅读本使用说明书，请保管好本说明书以备不时之用。


### 包装清单




### 电池充电

将电池与充电线连接，然后将USB充电线插入电脑的USB接口或USB的充电器上，然后接通电源。红灯亮时表示正在充电。红灯不亮时表示充满。


### 155-5A 遥控器功能




### 155-11A 遥控器功能



### 特技车及遥控器的电池安装和充电




- (1) 将遥控器底面的电池盖打开。
- (2) 按正确极性装入1.5V "AA" 电池2颗，盖上电池盖。




充电完成后，打开电池盖，将电池放进电池仓连接电池组和车身的接口，关上电池盖

### 操作方法

1、将遥控车的电源开关拨至“ON”位置。把遥控车放在平面上，再打开遥控器开关，待遥控指示灯停止闪烁，便可拨动操纵杆进行操作。(注：遥控器指示灯在闪烁时不能拨动操纵杆)



### 产品使用基本操作图



### 保养与维修

1. 长时间不玩，就要取出电池。
2. 用湿布来轻轻地抹车。
3. 勿把玩具放在高温，高潮及阳光直射的地方。
4. 不要把玩具放在水里，这样会损坏电子元件。

### 注意事项

- 安装或更换电池时请注意极性；
- 非充电电池不可充电；
- 当给充电电池充电时，需要成人监护；
- 不可使用新旧或不同类型的电池；
- 操作时，注意附近信号干扰，否则会影响遥控距离；
- 当特技车速减慢时，说明车体电量不足，请将特技车按以上方法充电即可
- 如遥控器电量不足，指示灯变暗或不亮，换新电池即可。
- 长时间不使用时，请取出遥控器内的电池，并将遥控车的电源开关拨到“OFF”位置，并取出遥控车车身的电池。

### 温馨提示


- 当车移动时，请不要用手触摸遥控车的四个车轮，以免损坏遥控车。



## STUNT CAR INSTRUCTION

Please read this instruction manual carefully before use, and properly keep this manual for future use.


### Packing list




### Battery charging

Connect the battery to the charging cable, then plug the USB charging cable into the USB port of the computer or the USB charger. Then turn on the power. When the red light is on, it means that charging is in progress, and when the red light is off it means the battery has been fully charged.


### 155-5A Remote Control Function




### 155-11A Remote Control Function



### Installation and charging method for the batteries of stunt car and remote control




Installation method of remote control battery  
(1) Open the battery cover on the backside of the remote control.  
(2) Insert 2x1.5V "AA" batteries with correct direction and cover the battery cover.




After charging is complete open the battery cover and place the battery in the battery compartment. Connect the battery pack to the stunt car connector and close the battery cover

### Operation Method

Turn on the car's power switch, On a flat surface, stops flashing, you can operate the joystick and begin playing. Remark: Cannot operate the joystick when the transmitter indicator is flashing.



### Basic operation picture showing how to USE this product



### Care & Maintenance

- (1) If you plan to stop use for a long time, remember to remove all the batteries.
- (2) If necessary, use a wet towel to gently wipe the car body clean.
- (3) Do not expose this toy to high temperature, high humidity or direct sunlight.
- (4) Do not put this toy in water to avoid damaging its electronic components.

### Cautions

- Pay attention to the direction when installing or replacing batteries; ● Do not use non-rechargeable batteries; ● When charging the rechargeable battery, adult guardianship is required;
- Do not mix old and new batteries or different types of batteries; ● During the operation, please pay attention to the nearby interference signal, otherwise the remote control distance will be affected;
- If the speed of the truck becomes more and more slow, it means the battery power is low; please change the military truck as per the above method. ● Please replace the battery in the following cases: the battery of the remote control is low; it is unable to charge the truck and the charging indicator becomes dark or is not turned on. ● Please take out the battery in the remote control and take out the battery. put the power switch of the truck to the "OFF" position if the truck is not used for a long time.

### USE Cautions

When the car is in motion, do not touch the wheels by hand to avoid damages to the car.

