


QUICK START GUIDE

BEAM
PARTYLIGHT

JBL


by HARMAN

WHAT'S IN THE BOX



*Power cord quantity and plug type vary by regions.

POWER ON




Avoid direct eye contact.

WORK WITH PARTYBOX



🎤: When is off, the built-in mic detects ambient sound, and the light effect adapts dynamically.

LIGHTSHOW




APP



Download and install the JBL ONE / JBL PARTYBOX app to get more from the product.



ADJUSTABLE ANGLE



TECH SPEC

LED:	RGB x 3; W LED x 4
Input:	100 - 240V ~ 50/60Hz
Power consumption:	22W
Cable type:	AC power cable (type varies by regions)
Cable length:	2 m / 6.6 ft
Bluetooth version:	5.3
Bluetooth modulation:	GFSK

Bluetooth transmitter frequency range:	2400 MHz - 2483.5 MHz
Bluetooth transmitter power:	< 12 dBm (EIRP)
Product dimensions (W x H x D):	152 mm x 156 mm x 96 mm / 5.98" x 6.14" x 3.78"
Net weight:	0.92 kg / 2.03 lbs
Packaging dimensions (W x H x D):	221 mm x 221 mm x 181 mm / 8.70" x 8.70" x 7.13"
Gross weight:	1.65 kg / 3.64 lbs



Do not look directly at the light-emitting parts when the lights are turned on.

FR Ne regardez pas directement les émissions de lumière lorsque les éclairages sont allumés.

CZ Když jsou světla zapnutá, nedívejte se přímo do částí vyzařujících světlo.

DA Se ikke direkte på de dele, der udsender lys, når lysene er tændt.

DE Nicht direkt in die Licht-emittierenden Teile blicken, wenn die Leuchten eingeschaltet sind.

EL Μην κοιτάτε απευθείας τα μέρη που εκπέμπουν φως όταν τα φώτα είναι αναμμένα.

ES No mire directamente a las partes que emiten luz cuando las luces están encendidas.

FI Älä katso suoraan valoa säteileviin osiin, kun valot ovat päällä.

HU Ne nézzen közvetlenül a fényt kibocsátó részekre, amikor a lámpák be vannak kapcsolva.

IT Non guardare direttamente le parti che emettono luce quando le luci sono accese.

NL Kijk niet rechtstreeks in de lichtgevende onderdelen wanneer de verlichting is ingeschakeld.

NO Ikke se rett på de lysemitterende delene når lampene er slått på.

PL Nie patrz bezpośrednio w części emitujące światło, gdy światła są włączone.

PT-BR Não olhe diretamente para as partes que emitem luz quando as luzes estiverem ligadas.

SK Keď sú svetlá zapnuté, nepozerajte sa priamo do častí vyžarujúcich svetlo.

SV Titta inte direkt på ljuskällorna när lamporna är påslagna.

TR Işıklar açıkken ışık çıkan parçalara doğrudan bakmayın.

RU Не смотрите прямо на светоизлучающие детали при включенном освещении.

UK Коли увімкнені світлові прилади, не дивіться прямо на світловіпромінювальні елементи.

ZH-CN 开灯时, 请勿直视发光部件。

ZH-TW 當燈光開啟時, 不要直視發光部件。

ID Jangan melihat secara langsung ke arah komponen pemancar cahaya yang sedang menyala.

JP ライトがオンの時は、発光部を直接見ないでください。

KO 조명이 켜져 있을 때 발광부를 직접 쳐다보지 마십시오.

MM အလင်းရောင်များ ထွက်လာသည့်အခါ အလင်းထုတ်လွှတ်သည့် အစိတ်အပိုင်းများကို မျက်စိနှင့်တိုက်ရိုက်မကြည့်ပါနှင့်။

AR لا تنظر مباشرةً إلى الأجزاء التي ينبعث منها الضوء عند تشغيل المصابيح.

HE אין להביט ישירות בחלקים פולטי האור כאשר התאורה דולקת.

RISK GROUP 2

CAUTION Possibly hazardous optical radiation emitted from this product. Do not stare at operating lamp. May be harmful to the eyes.

The light source contained in this luminaire shall only be replaced by the manufacturer or his service agent or a similar qualified person.

This product contains a light source of energy efficiency class D.



This equipment is a Class II or double insulated electrical appliance



The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by HARMAN International Industries, Incorporated is under license. Other trademarks and trade names are those of their respective owners.



Este produto está homologado pela Anatel, de acordo com os procedimentos regulamentados para avaliação da conformidade de produtos para telecomunicações e atende aos requisitos técnicos aplicados.

Para maiores informações, consulte o site da Anatel – www.anatel.gov.br

Este equipamento não tem direito à proteção contra interferência prejudicial e não pode causar interferência em sistemas devidamente autorizados.





PARTYLIGHT BEAM

Bluetooth projection party light



Make your party vibe.

An unforgettable party doesn't just sound incredible—it should look amazing too. Now you can create your own immersive environment with the JBL PartyLight Beam. This light wirelessly syncs with your JBL PartyBox speakers to project a colorful and kinetic party light—one that's big enough to cover a large room—onto any wall or ceiling. (And if you're partying in an even bigger space, you can sync multiple PartyLight Beams to create a choreographed lightshow in less than a minute.) Adjust the angle to center the light show where you want it and let the vibrant colors match your party's energy throughout the night—from mellow ambient grooves to epic dance beats to the pure delirium of your party's peak energy. Control the adjustable motion, speed, and intensity settings quickly and easily with the JBL PartyBox app. Elevate your party space to the next level with the unbeatable combination of the JBL PartyBox and JBL PartyLight Beam.

Features

- ▶ Take your party to the next level
- ▶ Room-filling party atmosphere
- ▶ Choreographed Lightshow
- ▶ Built-in mic with a music detection algorithm
- ▶ Match your energy
- ▶ JBL ONE app / PartyBox app
- ▶ Easy to turn the light on and off





PARTYLIGHT BEAM

Bluetooth projection party light



Features and Benefits

Take your party to the next level

The JBL PartyLight Beam syncs automatically with JBL PartyBox* lightshow or your music, turning your party into an awesome sensory experience.

*Auracast enabled

Room-filling party atmosphere

Just one JBL PartyLight Beam can fill a room up to 400 square feet (40 square meters) with 20 watts of immersive light shows.

Choreographed Lightshow

With multiple JBL PartyLight Beams connected together, the built-in music detection algorithm will create an even bigger group lightshow—all in less than a minute.

Built-in mic with a music detection algorithm

Even though the JBL PartyLight Beam is designed to pair with PartyBox speakers, you can also use it on its own. Featuring a built-in microphone and a music detection algorithm, the JBL PartyLight Beam automatically identifies and syncs to any music device that's playing.

Match your energy

Set the mood of the moment with adjustable motion, speed, and intensity levels that take the vibe from mellow to medium to peak party excitement.

JBL ONE app / PartyBox app

Use the JBL ONE app or PartyBox app to adjust lightshow's speed, colors, patterns and even connect multiple JBL PartyLight Beams, right at your fingertips.

Easy to turn the light on and off

Rotate the JBL PartyLight Beam to turn it on. Swing it back into position to turn it back off. It's that simple.

Technical Specifications

- ▶ LED: RGB x 3; W LED x 4
- ▶ Power input: 100-240V, 50~60Hz
- ▶ Power consumption: 22W
- ▶ Cable type: AC power cable (type varies by regions)
- ▶ Cable length: 2m/ 6.6ft
- ▶ Bluetooth® version: 5.3
- ▶ Bluetooth® transmitter modulation: GFSK
- ▶ Bluetooth® transmitter frequency range: 2400 MHz - 2483.5 MHz
- ▶ Bluetooth® transmitter power: < 12 dBm (EIRP)
- ▶ Product dimensions (W x H x D): 152 mm x 156 mm x 96 mm / 5.98" x 6.14" x 3.78"
- ▶ Net weight: 0.92 kg / 2.03 lbs
- ▶ Packaging dimensions (W x H x D): 221 mm x 221 mm x 181 mm / 8.70" x 8.70" x 7.13"
- ▶ Gross weight: 1.65 kg / 3.64 lbs

What's in the Box

- 1 x JBL PartyLight
- 1 x Power Cord (*quantity and plug type vary by regions)
- 1 x Quick start guide
- 1 x Safety sheet and warranty card



HARMAN International Industries, Incorporated
8500 Balboa Boulevard, Northridge, CA 91329 USA
www.jbl.com

© 2024 HARMAN International Industries, Incorporated. All rights reserved. JBL is a trademark of HARMAN International Industries, Incorporated, registered in the United States and/or other countries. Features, specifications and appearance are subject to change without notice. Google and Chromecast built-in are trademarks of Google LLC. Amazon, Alexa and all related marks are trademarks of Amazon.com, Inc. or its affiliates.



Safety Instruction and Warranty Card

PRODUCT REGISTRATION

register.jbl.com

SIGN UP & STAY TUNED

Register your product • Registriere dein produkt • Registro del producto •
Enregistrez votre produit • Registro de Produto • 製品登録 •
Registrer dit produkt • Rekisteröl tuotteesi • Rejestracja produktu •
Registrera din produkt • Registreer je product

*Product registration may not be available for all countries



SCAN ME



HARMAN PRODUCT WARRANTY AGAINST DEFECTS

AUSTRALIA & NEW ZEALAND

Ingram Micro Pty Limited (ABN 45 112 487 966) of 61 Dunning Avenue, Rosebery NSW 2018 Australia "**Ingram Micro ("Distributor")**" and Ingram Micro NZ Limited (NZBN 9429040004006) of 78 Apollo Drive, Auckland, New Zealand "**Ingram Micro ("Distributor")**" and Pacificomm Group Limited (NZBN: 9429000115117) 33 Westpoint Drive, Hobsonville, Auckland, New Zealand, 0618 **Pacificomm ("Distributor")** are authorised distributors of Harman International Ltd products ("**Products**") in Australia and New Zealand. Please refer to Harman's Warranty enclosed here for further information on Product warranty.

Warranty against defects:

Our goods (Products) come with guarantees that cannot be excluded under the Australian & New Zealand Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods (Products) repaired or replaced if the goods (Products) fail to be of acceptable quality and the failure does not amount to a major failure.

Harman Products are sold with warranty in compliance with Australian and New Zealand Consumer Law. In rare circumstances where the Products are found defective you shall be entitled to a repair, replacement or refund determined by the Distributor. Subject to the terms and conditions herein and Harman's Warranty, the Distributor will repair or replace, without charge for any manufacturing defects that appear in Harman Products within the warranty period identified in the product table below, commencing on the date of original purchase. You are entitled to have such defective Product repaired, replaced or a refund in accordance with your rights under law. The benefits given to you by this Warranty are in addition to the other rights and remedies you may have under the applicable law and nothing in this Warranty purports to restrict, modify or exclude your legal rights as a consumer under the relevant Australian and New Zealand law.

Warranty Claim Eligibility

1. This warranty applies only to products imported and distributed by Harman Distributors and sold to you within Australia or New Zealand. Except where an International Product Warranty has been provided with your Harman product, warranty service will only be provided in the specific country where the Harman product was originally purchased. For example, if you have purchased the Harman product within Australia, warranty service will be limited to Australia only.
2. This warranty is limited to defects that arise;
 - (a) in the course of normal domestic installation and use and
 - (b) within the warranty period identified for the product in the table below, commencing on the date of original purchase.
3. This warranty excludes
 - (a) defects arising from misuse, accident, neglect or improper care, fluctuation in electrical current, incorrect or failed software upgrade, damage or malfunction from incorrect assembly or installation, defects from alteration or modification, unauthorised service or repair;
 - (b) appearance of items such as cabinetry marks or damage, water or moisture entry or any pest infestation
 - (c) products on which the serial number has been defaced or removed; and
 - (d) force majeure or natural causes
4. Distributor may elect between repair, replacement, or refund to honour this warranty, at its sole discretion.

Brand	Category	Australia	New Zealand	Global Warranty
Harman Kardon	Sound Bars / SUB woofers	2 Years	1 Year	No
	Floor Speakers	2 Years	1 Year	
	Portable Speakers / Computer Speakers / Clock Radios	1 Year	1 Year	
	Headphones	1 Year	1 Year	
JBL	Sound Bar / SUB Woofers	2 Years	1 Year	
	Portable Speakers	1 Year	1 Year	
	Headphones	1 Year	1 Year	
	Gaming Headphones / Speakers	1 Year	1 Year	
	Computer Speakers / Radios / Clocks	1 Year	1 Year	
	Party Boxes – Consumer	1 Year	1 Year	
	Party Boxes – Pro Audio	2 Years	1 Year	
Infinity	Portable Speakers	1 Year	1 Year	
	Headphones	1 Year	1 Year	
	Battery Chargers / Battery Banks/ USB Cables	1 Year	1 Year	
Under Armour	Headphones	1 Year	1 Year	
Yurbuds	Headphones	1 Year	1 Year	
Accessories	Accessories which are not sold as part of other products but sold separately, such as optional Batteries.	1 Year	1 Year	
Not sure or your product is not listed: call + 61 2 9151 0376 in Australia or call +64 9 913 0453 in New Zealand or e-mail: support.apac@harman.com				

How to claim:

To make a claim under this warranty, you can contact Harman customer support team at + 61 2 9151 0376 in Australia, or call +64 9 913 0453 in New Zealand or email – support.apac@harman.com or the seller who sold you the Product. For up-to-date warranty information, your product warranty details and registering your product for warranty visit <https://www.ibl.com.au> in Australia and <https://www.ibl.co.nz/> in New Zealand. For Harman/Kardon Products please visit support pages <https://www.harmankardon.com.au/> in Australia, <https://www.harmankardon.co.nz/> in New Zealand.

ENGLISH

Download the full warranty card and safety information and other helpful information from our website: www.jbl.com/warrantyandsafetybooks

ČEŠTINA

Úplný záruční list, bezpečnostní pokyny a další užitečné informace lze stáhnout z našeho webu: www.jbl.com/warrantyandsafetybooks

DANSK

Hent det komplette garantiark og sikkerhedsoplysninger og andre nyttige oplysninger fra vores hjemmeside: www.jbl.com/warrantyandsafetybooks

DEUTSCH

Lade die vollständige Garantiekarte und Sicherheitsinformationen sowie weitere hilfreiche Informationen von unserer Website herunter: www.jbl.com/warrantyandsafetybooks

EESTI

Laadige alla täielik garantiikaart, ohutusteave ja muu kasulik teave meie veebisaidilt: www.jbl.com/warrantyandsafetybooks

ΕΛΛΗΝΙΚΑ

Κατεβάστε την πλήρη κάρτα εγγύησης και πληροφορίες ασφάλειας και άλλες χρήσιμες πληροφορίες από τον ιστότοπό μας: www.jbl.com/warrantyandsafetybooks

ESPAÑOL

Descarga la tarjeta de garantía completa, la información de seguridad y otra información útil de nuestro sitio web: www.jbl.com/warrantyandsafetybooks

SUOMI

Lataa täydellinen takuukortti ja turvallisuustiedot, sekä muut hyödylliset tiedot verkkosivuiltamme: www.jbl.com/warrantyandsafetybooks

FRANÇAIS

Téléchargez la carte de garantie et les informations de sécurité complètes ainsi que d'autres informations utiles sur notre site Web: www.jbl.com/warrantyandsafetybooks

HRVATSKI

Preuzmite punu jamstvenu karticu, sigurnosne informacije i ostale korisne informacije s našeg web mjesta: www.jbl.com/warrantyandsafetybooks

MAGYAR

Töltse le a teljes garanciakártyát, a biztonságos információkat és egyéb hasznos információkat a weboldalunkról: www.jbl.com/warrantyandsafetybooks

ITALIANO

Scarica la scheda di garanzia completa, le informazioni sulla sicurezza e altre informazioni utili dal nostro sito Web: www.jbl.com/warrantyandsafetybooks

LIETUVIŲ KALBA

Atsisiųskite visą garantijos kortelę ir saugos informaciją bei kitą naudingą informaciją iš mūsų svetainės: www.jbl.com/warrantyandsafetybooks

LATVISKI

Lejupielādējiet pilnu garantijas karti, informāciju par drošību un citu noderīgu informāciju mūsu vietnē: www.jbl.com/warrantyandsafetybooks

NEDERLANDS

Download de volledige garantiekaart en veiligheidsinformatie en andere nuttige informatie van onze website: www.jbl.com/warrantyandsafetybooks

NORSK

Last ned det komplette garantikortet, sikkerhetsinformasjon og annen nyttig informasjon fra nettstedet vårt: www.jbl.com/warrantyandsafetybooks

POLSKI

Prosimy pobrać kartę gwarancyjną, informacje o bezpieczeństwie oraz inne przydatne informacje z naszej strony internetowej: www.jbl.com/warrantyandsafetybooks

PORTUGUÊS

Descarregue por completo o Cartão de garantia e informações de segurança e outras informações úteis no nosso site: www.jbl.com/warrantyandsafetybooks

PORTUGUÊS (BRASIL)

O Cartão de Garantia, informações de segurança e outras informações úteis estão disponíveis no site www.jbl.com/warrantyandsafetybooks

ROMÂNĂ

Descărcați fișa completă de garanție, informații de siguranță și alte informații de ajutor de pe site-ul web: www.jbl.com/warrantyandsafetybooks

SLOVENŠČINA

Prenesite celoten garancijski list in varnostne informacije ter druge koristne napotke z naše spletne strani: www.jbl.com/warrantyandsafetybooks

SVENSKA

Ladda ner hela garantikortet och säkerhetsinformation och annan användbar information från vår webbplats: www.jbl.com/warrantyandsafetybooks

TÜRKÇE

Komple garanti kartını ve güvenlik bilgilerini ve yardımcı bilgileri websitemizden indirin: www.jbl.com/warrantyandsafetybooks

БЪЛГАРСКИ

Изтеглете пълната гаранционна карта и информация за безопасност и друга полезна информация от нашия уебсайт: www.jbl.com/warrantyandsafetybooks

РУССКИЙ

Загрузите полностью гарантийный талон, информацию по технике безопасности и другую полезную информацию с нашего веб-сайта: www.jbl.com/warrantyandsafetybooks

简体中文

请登录我公司网站下载完整的保修卡和安全信息及其他有用信息: www.jbl.com/warrantyandsafetybooks

繁體中文

從我們的網站下載完整的保固卡和安全資訊及其他有用資訊: www.jbl.com/warrantyandsafetybooks

BAHASA INDONESIA

Unduh kartu garansi lengkap serta informasi keamanan dan informasi bermanfaat lainnya dari situs web kami: www.jbl.com/warrantyandsafetybooks

日本語

下記のウェブサイトから保証書、安全情報、その他の役立つ情報をダウンロードしてください: www.jbl.com/warrantyandsafetybooks

한국어

전체 품질보증서와 안전 정보를 비롯해 기타 유용한 정보를 다음 당사 웹 사이트에서 다운로드하십시오. www.jbl.com/warrantyandsafetybooks

العربية

قم بتنزيل بطاقة الضمان الكاملة ومعلومات السلامة وغيرها من المعلومات المفيدة من على موقعنا على الإنترنت: www.jbl.com/warrantyandsafetybooks

עברית


ניתן להוריד את הנוסח המלא של תעודת האחריות ומידע בנושא בטיחות, כמו גם מידע שימושי נוסף, מאתר האינטרנט שלנו: www.jbl.com/warrantyandsafetybooks



ENGLISH

IMPORTANT SAFETY INSTRUCTIONS

For all products:

1. Clean only with a dry cloth.
2. Do not block any ventilation openings. Install this apparatus in accordance with the manufacturer's instructions.
3. Do not install this apparatus near any heat sources such as radiators, heat registers, stoves or other apparatus (including amplifiers) that produce heat.
4. Do not defeat the safety purpose of the polarized or grounding-type plug. A polarized plug has two blades with one wider than the other. A grounding-type plug has two blades and a third grounding prong. The wide blade or the third prong is provided for your safety. If the provided plug does not fit into your outlet, consult an electrician for replacement of the obsolete outlet.
5. Protect the power cord from being walked on or pinched, particularly at plugs, convenience receptacles and the point where they exit from the apparatus.
6. Use only attachments/accessories specified by the manufacturer.
7. Use only with the cart, stand, tripod, bracket or table specified by the manufacturer or sold with the apparatus. When a cart is used, use caution when moving the cart/apparatus combination to avoid injury from tip-over. 
8. Unplug this apparatus during lightning storms or when unused for long periods of time.
9. Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as when the power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, or the apparatus has been exposed to rain or moisture, does not operate normally or has been dropped.
10. To disconnect this apparatus from the AC mains completely, disconnect the power-supply cord plug from the AC receptacle.
11. The mains plug of the power-supply cord shall remain readily operable.
12. This apparatus is intended to be used only with the power supply and/or charging cable provided by the manufacturer.

The following instructions may not apply to waterproof devices. Refer to your device user manual or quick start guide for more waterproof instruction if any.

- Do not use this apparatus near water.
- Do not expose this apparatus to dripping or splashing, and ensure that no objects filled with liquids, such as vases, are placed on the apparatus.

WARNING: TO REDUCE THE RISK OF FIRE OR ELECTRIC SHOCK, DO NOT EXPOSE THIS APPARATUS TO RAIN OR MOISTURE.

CAUTION

RISK OF ELECTRIC SHOCK. DO NOT OPEN.



THIS SYMBOL ON THE PRODUCT MEANS THERE IS UNINSULATED, DANGEROUS VOLTAGE WITHIN THE PRODUCT ENCLOSURE THAT MAY PRESENT A RISK OF ELECTRICAL SHOCK.



THIS SYMBOL ON THE PRODUCT MEANS THERE ARE IMPORTANT OPERATING AND MAINTENANCE INSTRUCTIONS IN THIS GUIDE.

CAUTION FCC AND IC STATEMENT FOR USERS

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

CAN ICES-003(B)/NMB-003(B)

FCC SDOC SUPPLIER'S DECLARATION OF CONFORMITY

HARMAN International hereby declares that this equipment is in compliance with the FCC Part 15 Subpart B.

Federal Communication Commission Interference Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Changes or modifications not expressly approved by HARMAN could void the user's authority to operate the equipment.

For Products That Transmit RF Energy:

(i) This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:

- (1) This device may not cause interference.
- (2) This device must accept any interference, including interference that may cause undesired operation of the device.

(ii) Radiation Exposure statement

This equipment complies with FCC and IC RSS-102 radiation exposure limits set forth for an uncontrolled environment.

For radio equipment operates in 5150-5850MHz

FCC and IC Caution:

High power radars are allocated as primary users of the 5.25 to 5.35 GHz and 5.65 to 5.85 GHz bands. These radar stations can cause interference with and/or damage to LE LAN (Licence-Exempt Local Area Network) devices. No configuration controls are provided for this wireless equipment allowing any change in the frequency of operations outside the FCC grant of authorization for US operation according to Part 15.407 of the FCC rules.

IC Caution:

User should also be advised that:

- (i) The device for operation in the band 5150 - 5250 MHz is only for indoor use to reduce the potential for harmful interference to co-channel mobile satellite systems;
- (ii) The maximum antenna gain permitted for devices in the bands 5250 - 5350 MHz and 5470 - 5725 MHz shall comply with the e.i.r.p. limit; and
- (iii) The maximum antenna gain permitted for devices in the band 5725 - 5825 MHz shall comply with the e.i.r.p. limits specified for point-to-point and non point-to-point operation as appropriate.

Use Restriction Attention in European Union, operation is limited to indoor use within the band 5150-5350 MHz.

Correct disposal of this product (Waste Electrical & Electronic Equipment)

This symbol means the product must not be discarded as household waste, and should be delivered to an appropriate collection facility for recycling. Proper disposal and recycling helps protect natural resources, human health and the environment. For more information on disposal and recycling of this product, contact your local municipality, disposal service, or the shop where you bought this product.



This product is RoHS compliant.

This product is in compliance with Directive 2011/65/EU and UK The Restriction of the Use of Certain Hazardous Substances in Electrical and Electronic Equipment Regulations 2012, and its amendments, on the restriction of the use of certain hazardous substances in electrical and electronic equipment.

REACH

REACH (Regulation No 1907/2006) addresses the production and use of chemical substances and their potential impacts on human health and the environment. Article 33(1) of REACH Regulation requires suppliers to inform the recipients if an article contains more than 0.1 % (per weight per article) of any substance(s) on the Substances of Very High Concern (SVHC) Candidate List ("REACH candidate list"). This product may contain the substance "lead" (CAS-No. 7439-92-1) in a concentration of more than 0.1% per weight. At the time of release of this product, except for the lead substance, no other substances of REACH candidate list are contained in a concentration of more than 0.1% per weight in this product.

Note: On June 27, 2018, lead was added to the REACH candidate list. The inclusion of lead in the REACH candidate list does not mean that lead-containing materials pose an immediate risk or results in a restriction of permissibility of its use.

For devices with headphone jacks

WARNINGS/CAUTIONS



Do NOT use the headphones at a high volume for any extended period.

- To avoid hearing damage, use your headphones at a comfortable, moderate volume level.
- Turn the volume down on your device before placing the headphones on your ears, then turn the volume up gradually until you reach a comfortable listening level.

For Products That Include Batteries

Instructions for Users on Removal, Recycling and Disposal of Used Batteries

To remove the batteries from your equipment or remote control, reverse the procedure described in the owner's manual for inserting batteries. For products with a built-in battery that lasts for the lifetime of the product, removal may not be possible for the user. In this case, recycling or recovery centers handle the dismantling of the product and the removal of the battery. If, for any reason, it becomes necessary to replace such a battery, this procedure must be performed by authorized service centers. In the European

Union and other locations, it is illegal to dispose of any battery with household trash. All batteries must be disposed of in an environmentally sound manner. Contact your local waste-management officials for information regarding the environmentally sound collection, recycling and disposal of used batteries.

WARNING: Danger of explosion if battery is incorrectly replaced. To reduce risk of fire, explosion or leakage of flammable liquid/gas, don't disassemble, crush, puncture, short external contacts, expose to temperature above 60°C (140°F), sunshine or like, expose to extremely low air pressure or dispose of in fire or water. Replace only with specified batteries. The symbol indicating 'separate collection' for all batteries and accumulators shall be the crossed-out wheeled bin shown below:



WARNING - For Products Contain Coin/Button Cell Batteries

DO NOT INGEST BATTERY, CHEMICAL BURN HAZARD. This product contains a coin/button cell battery. If the coin/button cell battery is swallowed, it can cause severe internal burns in just 2 hours and can lead to death. Keep new and used batteries away from children. If the battery compartment does not close securely, stop using the product and keep it away from children. If you think batteries might have been swallowed or placed inside any part of the body, seek immediate medical attention.

For All Products with Wireless Operation:

HARMAN International hereby declares that this equipment is in compliance with the essential requirements and other relevant provisions of Directive 2014/53/EU and UK Radio Equipment Regulations 2017. The declaration of conformity may be consulted in the spec section of the product detail page, accessible from www.jbl.com or in www.jbl.com/doc.

HARMAN International Industries, Incorporated. All rights reserved. JBL is a trademark of HARMAN International Industries, Incorporated, registered in the United States and/or other countries. Features, specifications and appearance are subject to change without notice.



www.jbl.com

ČEŠTINA

DŮLEŽITÉ BEZPEČNOSTNÍ POKYNY

U všech výrobků:

- Čistěte pouze suchým hadříkem.
- Neblokujte žádné větrací otvory. Instalaci spotřebiče provádějte podle pokynů výrobce.
- Spotřebič neinstalujte v blízkosti zdrojů tepla, jako jsou radiátory, tepelné registry, kamna nebo jiná zařízení (včetně zesilovačů), které produkují teplo.
- Nemávejte bezpečnostní úhel polarizované nebo uzemněné zástrčky. Polarizovaná zástrčka je opatřena dvěma plochými kontakty, kdy jeden je širší než druhý. Uzemňovací zástrčka má dva ploché kontakty a třetí uzemňovací kolík. Pro vaši bezpečnost je k dispozici široký kontakt nebo třetí kolík. Pokud dodaná zástrčka nezapadá do vaší zásuvky, požádejte elektrikáře o výměnu zastaralé zásuvky.
- Napájecí kabel chraňte před pošlapáním nebo skřípnutím, zejména v okolí zástrček, zásuvek a na místech, kde vystupují ze zařízení.
- Používejte pouze příslušenství/doplňky určené výrobcem.
- Používejte pouze vozíky, podstavce, stativy, držáky či stojky doporučené výrobcem nebo prodávané se zařízením. Při používání vozíku buďte opatrní při přemisťování kombinace vozíku/přístroje, abyste zabránili poranění převrácením.
- Odpojte přístroj během bouřek nebo po dlouhé době nečinnosti.
- Veškeré opravy může provádět pouze kvalifikovaný servis. Pokud byl přístroj jakýmkoli způsobem poškozen, například když je poškozen napájecí kabel nebo zástrčka, došlo k rozliti kapaliny nebo do přístroje spadly předměty, přístroj byl vystaven dešti nebo vlhkosti, nefunguje normálně nebo byl upuštěn, je vyžadována údržba.
- Chcete-li spotřebič zcela odpojit od sítě, odpojte zástrčku napájecího kabelu ze zásuvky.
- Síťová zástrčka napájecího kabelu musí zůstat snadno funkční.
- Spotřebič je určen k použití pouze s napájecím a/nebo nabíjecím kabelem poskytnutým výrobcem.



Následující pokyny se nemusí vztahovat na vodotěsná zařízení. Další případné pokyny ohledně vodotěsnosti najdete v návodu k použití zařízení nebo ve stručné příručce.

- Přístroj nepoužívejte v blízkosti vody.
- Přístroj nevystavujte kapající nebo stříkající vodě a zajistěte, abyste na něj nepokládali žádné předměty naplněné kapalinami, například vázy.

VÝSTRAHA: CHCETE-LI SNÍŽIT RIZIKO POŽÁRU NEBO ÚRAZU ELEKTRICKÝM PROUDEM, NEVYSTAVUJTE SPOTŘEBIČ DEŠTI NEBO VLHKU.

VÝSTRAHA

NEBEZPEČÍ ÚRAZU ELEKTRICKÝM PROUDEM. NEOTEVÍRAT.



TENTO SYMBOL NA VÝROBKU ZNAMENÁ, ŽE UVNITŘ KRYTÍ VÝROBKU JE NEIZOLOVANÉ NEBEZPEČNÉ NAPĚTÍ, KTERÉ MŮŽE PŘEDSTAVOVAT RIZIKO ÚRAZU ELEKTRICKÝM PROUDEM.



TENTO SYMBOL NA VÝROBKU ZNAMENÁ, ŽE JSOU V TOMTO NÁVODU DŮLEŽITÉ POKYNY O PROVOZU A ÚDRŽBĚ.

Správná likvidace tohoto výrobku (odpadní elektrická a elektronická zařízení)

Tento symbol znamená, že výrobek nesmí být zlikvidován jako domácí odpad a měl by být dodán do příslušného sběrného zařízení k recyklaci. Správná likvidace a recyklace pomáhá chránit přírodní zdroje, lidské zdraví a životní prostředí. Další informace o likvidaci a recyklaci výrobku získáte u místní samosprávy, u služby likvidace odpadu nebo v obchodě, kde jste výrobek zakoupili.



Tento výrobek je ve shodě se směrnicí RoHS

Tento výrobek je v souladu se směrnicí 2011/65/EU o omezení používání některých nebezpečných látek v elektrických a elektronických zařízeních.

REACH

Nařízení REACH (nařízení č. 1907/2006) se týká výroby a používání chemických látek a jejich potenciálních dopadů na lidské zdraví a životní prostředí. Čl. 33 odst. 1 nařízení REACH vyžaduje, aby dodavatelé informovali příjemce, pokud výrobek obsahuje více než 0,1 % (na hmotnost na výrobek) jakékoli látky (látek) ze seznamu látek vzbuzujících mimořádné obavy (SVHC) (dále jen „seznam kandidátů REACH“). Tento produkt může obsahovat látku „olovo“ (č. CAS 7439-92-1) v koncentraci vyšší než 0,1 % hmotnosti.

V době vydání tohoto výrobku, s výjimkou hlavní látky, neobsahují žádné jiné látky ze seznamu látek pro případné zahrnutí do přílohy XIV nařízení REACH v koncentraci vyšší než 0,1 % hmotnosti v tomto výrobku.

Poznámka: 27. června 2018 bylo na seznam kandidátů podle nařízení REACH přidáno olovo. Zahrnutí olova do seznamu kandidátů REACH neznamená, že materiály obsahující olovo představují bezprostřední riziko nebo mají za následek omezení přípustnosti jeho použití.

U zařízení s konektorem sluchátek

VAROVÁNÍ/UPOZORNĚNÍ



NEPOUŽÍVEJTE sluchátka po delší dobu při vysoké hlasitosti.
- Abyste předešli poškození sluchu, používejte sluchátka při pohodlné a střední úrovni hlasitosti.
- Před nasazením sluchátek na uši snižte hlasitost zařízení a poté ji postupně zesilujte, dokud nedosáhnete pohodlné úrovně poslechu.

U výrobků obsahujících baterie

Pokyny pro uživatele ohledně vyjímání, recyklace a likvidace použitých baterií

Při vyjímání baterií ze zařízení nebo dálkového ovladače použijte opačné pořadí postupu vkládání baterií popsané v návodu k obsluze. U výrobků s vestavěnou baterií, která vydrží po celou dobu životnosti výrobku, nemusí být vyjmuti pro uživatele možné. V tomto případě řeší demontáž výrobku a vyjmutí baterií recyklační nebo regenerační střediska. Pokud je v libovolném případě nutné baterie vyjmout za účelem recyklace nebo využití, musí to být provedeno v autorizovaných servisních střediscích. V Evropské unii a na jiných místech je nezákonem likvidovat jakoukoli baterii spolu s domácím odpadem. Všechny baterie musí být zlikvidovány způsobem šetrným k životnímu prostředí. Informace o sběru, recyklaci a likvidaci použitých baterií získáte od místních pracovníků pro nakládání s odpady.

VÝSTRAHA: Při nesprávném provedení výměny baterie hrozí nebezpečí výbuchu. Abyste snížili riziko požáru, výbuchu nebo úniku hořlavé kapaliny/plynu, nerozebírejte, nedrte, nepropíchněte, nezkratujte vnější kontakty, nevystavujte teplotě nad 60 °C (140 °F), slunci apod., nevystavujte extrémně nízkému vzdušnému tlaku ani nelikvidujte v ohni nebo ve vodě. Vyměňujte pouze za určené baterie. Symbol označující „oddělený sběr“ musí být u všech baterií a akumulátorů označen níže uvedeným přeškrtnutým odpadkovým košem:



VAROVÁNÍ – u výrobků obsahujících knoflíkové baterie

BATERII NEPOLYKEJTE, NEBEZPEČÍ CHEMICKÉHO POPÁLENÍ. Tento výrobek obsahuje knoflíkovou baterii. Pokud je knoflíková baterie spolknuta, může za 2 hodiny způsobit vážné vnitřní popáleniny a může způsobit smrt. Nové i staré baterie chraňte před dětmi. Pokud nelze přiblížku pro baterii bezpečně zavřít, přestaňte výrobek používat a uložte ho mimo dosah dětí. Pokud si myslíte, že mohly být baterie spolknuty nebo se dostaly dovnitř některé části těla, ihned vyhledejte lékařskou pomoc.

U všech výrobků s bezdrátovým provozem:

Společnost HARMAN International prohlašuje, že je toto zařízení v souladu se základními požadavky a dalšími ustanoveními směrnice 2014/53/EU. Prohlášení o shodě je k nahlédnutí v sekci specifikace na stránce s podrobnostmi o výrobku, která je dostupná na www.jbl.com nebo na www.jbl.com/doc.

HARMAN International Industries, Incorporated. Všechna práva vyhrazena. JBL je ochranná známka společnosti HARMAN International Industries, Incorporated, registrovaná ve Spojených státech a/nebo jiných zemích. Funkce, parametry a vzhled se mohou změnit bez předchozího upozornění.



www.jbl.com



WARRANTY CARD / CARTÃO DE GARANTIA / 제품보증서 / 产品保修卡 / 品質保証書 / WARRANTY AU&NZ

EN WARRANTY CARD

SET UP INFORMATION & PRODUCT REGISTRATION

Congratulations with the purchase of your new Product. We have done our utmost to make your experience the best one possible. If you have any questions when setting up your Product and would like some helpful hints, we recommend that you visit the relevant country specific support website for your Product: www.jbl.com. There you will also find relevant contact information. If you cannot find the information you are looking for, please contact the vendor that sold the Product to you or contact the relevant JBL customer support center by electronic mail or phone.

We recommend that you register your Product via the relevant country specific website for your Product. Your registration will allow us to inform you about updates for certain products, possible new offers and new Products and/or applications. Registering is easy; just follow the instructions on the relevant country specific website for your Product.

NOTE: THIS LIMITED WARRANTY DOES NOT APPLY TO CONSUMERS IN THE EUROPEAN ECONOMIC AREA (EEA) MEMBER STATES, AUSTRALIA AND NEW ZEALAND AS THEY ARE PROTECTED BY LOCAL CONSUMER LAW AND BENEFIT FROM LOCAL STATUTORY WARRANTIES

LIMITED WARRANTY

WHO IS PROTECTED BY THE WARRANTY

This limited warranty (the "Limited Warranty") protects only the original end-user ("you" or "your"), and is not transferable and is applicable only in the country (excluding EEA member states and the Russian Federation) in which you originally purchased your JBL Product (the "Product"). Any attempt to transfer this warranty shall immediately make this warranty void.

LIMITED WARRANTY

HARMAN International Industries, Incorporated ("HARMAN") is the manufacturer and through its local subsidiary, warrants to you that the Product (including components provided in/with the Product) will be free from defects in workmanship and materials for a period of ONE year from the date of retail purchase by you (the "Warranty Period"). During the Warranty Period, the Product (including components), will be repaired or replaced at HARMAN's option, without charge for either parts or labor OR at HARMAN's sole option, the price of the Product may be refunded, subject to depreciation based on your purchase price for the Product pro-rated over the remaining balance of the Warranty Period. Any warranty service or replacement of parts will not extend the Warranty Period.

This Limited Warranty does not cover defects which are a result of: (1) damage caused by accident, unreasonable use or neglect (including the lack of reasonable and necessary maintenance); (2) damage during shipment (claims must be presented to the carrier); (3) damage to, or deterioration of, any accessory or decorative surface; (4) damage resulting

from failure to follow instructions contained in your owner's manual; (5) damage resulting from the performance of repairs by someone other than an authorized JBL service center; (6) deterioration of component parts, the nature of which is to become worn or depleted with use, such as batteries and headphone ear pads.

Furthermore, this Limited Warranty covers only actual defects within the Product itself, and does not cover the cost of installation or removal from a fixed installation, setup or adjustments, claims based on misrepresentation by the seller, performance variations resulting from installation-related circumstances such as source quality or AC power or Product modifications, any unit on which the serial number has been effaced, modified or removed, or units used for other than home use. This Limited Warranty is valid only for JBL products purchased from an authorized dealer.

Except to the extent expressly prohibited in your jurisdiction by applicable law, all implied warranties, including fitness for a particular purpose and merchantability are hereby excluded and in no event shall HARMAN or any HARMAN subsidiary be liable for any indirect, direct, incidental, special or consequential loss or damages whatsoever (including, without limitation, other pecuniary loss) arising out of the use of or inability to use the Product, even if HARMAN and/or a HARMAN subsidiary have been advised of the possibility of such damages. To any extent that HARMAN cannot lawfully disclaim implied warranties under this Limited Warranty, all such implied warranties are limited in duration to the duration of this warranty. Some jurisdictions do not allow the exclusion or limitation of incidental or consequential damages or exclusions or limitations on the duration of implied warranties or conditions, so the above limitations or exclusions may not apply to you. This warranty gives you specific legal rights, and you may also have other rights that vary by jurisdiction.

HOW TO OBTAIN WARRANTY SERVICE

Contact the dealer who sold you this Product, or contact JBL customer support using the contact information on the relevant country specific support website for your Product to request warranty service. To validate your right to this Limited Warranty, you must provide the original sales invoice or other proof of ownership and date of purchase. Do not return your Product without prior authorization from the corresponding dealer or HARMAN. Warranty repair of the HARMAN Product must be carried out by an authorized dealer or service center. Unauthorized warranty repair will void the warranty and is performed at your sole risk.

You are also welcome to consult the relevant country specific HARMAN support website for your Product for helpful hints.

WHO PAYS FOR WHAT

This Limited Warranty covers all expenses for labor and materials required for the repair OR replacement of the Product that is found to be defective, and a reasonable return shipping charge within the country of repair. Please be sure to save the original shipping carton(s), because a charge will be made for additional cartons/packaging.

You will be charged for the cost of examining a unit that is not in need of repair (including resulting shipping costs), or for necessary repairs not covered by this Limited Warranty.

We sincerely thank you for your expression of confidence in JBL. We wish you many years of listening pleasure.

HARMAN

HARMAN International Industries, Incorporated
8500 Balboa Boulevard, Northridge, CA 91329 USA
516.255.4545 (USA only)

SSA2020-002_JBL_Non HP_Safety&Warranty_(150 x 80mm)_V11