





## MAKE BEAUTY A NEW SMART

-  US: [service@melodysusie.com](mailto:service@melodysusie.com)
-  EU: [service.uk@melodysusie.com](mailto:service.uk@melodysusie.com)
-  <http://www.melodysusie.com>
-  Whipple Road, Union City, CA 94578

**EU REP** AMZLAB GmbH  
Laubenhof 23, 45326 Essen, Germany

**UK REP** THEMIS AR support ltd  
85 Great Portland St, London, United Kingdom, W1W 7LT



*melodysusie*

2 in 1 UV LED  
Nail Art Lamp  
**User Manual**

# INDEX

---

Important Safeguards .....	1
Items Included .....	3
How to Use .....	3
Charging .....	4
Malfunctions and Solutions .....	5
Specifications .....	6
Warranty and Customer Service .....	7

Thank you for choosing MelodySusie! Please read this user guide carefully and keep it in an accessible location so you may refer to it later.

## IMPORTANT SAFEGUARDS

### READ ALL INSTRUCTIONS BEFORE USING.



To reduce the risk of burns, electrocution, fire, or injury to persons.

Please be sure to read the safety instruction as follow to avoid potential hazards that could result in personal injuries or damage to the device.

**Note:** If the USB cord connects to the adapter, it is recommended to use an adapter of 5V 2A. Please do not exceed 5V 2A, or the device will burn out.

#### Note Before Using

1. Check the charging cord before the first use and during the life of the device. Do not use this device with a damaged cord, or when the device is not working properly or damaged. If the device or the power cord is damaged, it should be repaired or replaced by MelodySusie or another authorized professional.
2. Do not plug this device into a voltage system that is different from the voltage system specified on the device. Use with improper voltage will damage the device and VOID warranty.

3. Do not project the UV/LED light to the eyes, which will cause damage to the eyes.
4. Do not touch the device with a wet hand to prevent electric leakage and shock or fire.
5. Any misuse, dropping or excessive use may cause device damage.
6. Please turn the power off if you don't use the nail lamp for a long time, and store it properly to extend its lifetime.
7. Children under 18 years old should not use this device without parental consent and supervision.

#### Note for the Battery

1. Please fully charged the battery before your first use to ensure optimal performance.
2. Do not overcharge the device or use it when it is charging.
3. Charge the device in well-ventilated condition with 0°C ~ 40° C. Do not charge the device close to flammable or explosive materials. When charging the device, please do not cover it with clothes or other things.
4. If the device is not used for long periods of time, you should charge and discharge once every three months. In normal conditions, the battery performance will decline over several years.

#### Maintenance Work

1. Do not disassemble the device. Doing so could be dangerous and constitutes voiding warranty conditions.
2. Do not keep the device in a place that is about or more than 50°C (in a metal box, car, or other places at high temperature).

3. Store the device in a cool and dry place. Do not store it in a hot or humid environment.
4. Keep the charge cord away from heated surfaces.
5. Do not dispose of the device in heat or fire.
6. Do not clean the device with harmful chemicals or detergents.

The operator shall be responsible for any consequences including product damage or accidents if not strictly complies with the instructions. If you require any technical support, contact us at [service@melodysusie.com](mailto:service@melodysusie.com).

## Items Included

---

1 x 2 in 1 UV LED Nail Art Lamp


1 x USB Cord


1 x User Manual

## How to Use

---

**Step 1:** Press the "ON/OFF" button to power on the device.


**Step 2:** Touch the  to switch the light between the LED Light Mode and UV Light Mode.

**Step 3:** The UV Light Mode will switch into the LED Light Mode after 60 -seconds curing automatically. If you need to use the UV Light Mode again, simply press the  to switch the light.

**Step 4:** Press the "ON/OFF" button to power off the device.

### Note:

- **LED Light Mode:** Without curing function, can only provide the lighting requirement for manicure work.
- **UV Light Mode:** Work for nail gel polish curing. (When used in conjunction with MelodySusie Nail Lamp whose power higher than 48W.)



- |                         |                      |
|-------------------------|----------------------|
| 1 ON/OFF                | 5 Flexible Tube      |
| 2 LED Light/UV Light    | 6 Type-C Charge Jack |
| 3 Touch Switch          | 7 Charging Indicator |
| 4 Heat Dissipation Hole |                      |

## Charging

---

1. Connect the charging cord to the nail lamp.
2. Insert the charging cord with the 5V 2A adapter or other USB sockets.
3. Indicator will change from RED to GREEN when the device is fully charged.

## Malfunctions and Solutions

Malfunctions	Reasons	Solutions
Device drops to the ground or by other impacts	<ol style="list-style-type: none"><li>1. The ON/OFF button doesn't work</li><li>2. Nail Lamp damages</li></ol>	Avoid device drops or by other impacts
Long time, Large load work	Motor burns out, or device lifespan shortens	The continuous working time should not be too long when the working condition is in heavy load. When the device is overheating, it should be stopped immediately to make it return to normal temperature
The beads don't turn on	The LED light beads are defective, or the lamp's internal circuits are damaged	When the light beads are damaged, please contact MelodySusie customer service team for help
The gel nail polish cannot be cured or dried	Insufficient curing time may result in incomplete curing of your gel nail polish. The curing time requirements vary from different gel polish brands and colors	<ol style="list-style-type: none"><li>1. Please try to extend the curing time appropriately until the nail surface is completely cured</li><li>2. Please make sure the nail lamp is closer enough to your nails, and avoid moving your hand too much until curing is complete</li><li>3. Please adjust the nail light angle to make sure the light can reach your nails directly</li><li>4. When used in conjunction with MelodySusie Nail Lamp (Power higher than 48W)</li></ol>

<b>Malfunctions</b>	<b>Reasons</b>	<b>Solutions</b>
Overcharge	Battery lifespan shortens	Not exceed the specified charging time
Insert into a mismatched power supply	Motor burns out	According to the device voltage requirements insert the matching power supply
Put the power cord at random, or use the device when charging	<ol style="list-style-type: none"> <li>1. Battery damages and device lifespan shortens</li> <li>2. Power cord breaks</li> <li>3. Poor connection</li> </ol>	Do not pull the power cord, or do not use the device when charging
Water into the device, or operate in wet or moist conditions, or use a wet cloth to clean the	<ol style="list-style-type: none"> <li>1. Motor burns out</li> <li>2. Device lifespan shortens</li> </ol>	Do not operate in wet or moist conditions, only a dry cloth is allowed for cleaning

## Specifications

Max Input Voltage Range: 5V/2A

Battery Fully Charging Time: 2.5 hours

Email: [service@melodysusie.com](mailto:service@melodysusie.com)

Email: [service.uk@melodysusie.com](mailto:service.uk@melodysusie.com)

Website: [www.melodysusie.com](http://www.melodysusie.com)

## Warranty and Customer Service

MelodySusie offers a 6-month limited warranty on quality-related issues. **Please apply for your extra 6-month warranty extension by registering on [www.melodysusie.com](http://www.melodysusie.com) if needed.**

