


PHILIPS

hue

personal wireless lighting

T-connector / extension cable






HUE serial number




User manual
Benutzerhandbuch
Notice d'emploi
Manual de usuario
Manual do usuário
Manuale d'uso

A



- Use only with Philips Hue 24V SELV IP67 LED power supply!
- Verwendung nur mit Philips Hue 24V SELV IP67 LED-Stromversorgung!
- Utiliser uniquement avec l'alimentation LED Philips Hue 24V SELV IP67!
- Se utiliza solo con la fuente de alimentación LED Philips Hue SELV 24V IP67!
- Utilize apenas com fonte de alimentação LED SELV Philips Hue de 24V IP67!
- Da utilizzzare solo con un alimentatore LED Philips Hue 24V IP67!



Signify
I.B.R.S. / C.C.R.I. Numéro 10461
5600 VB Eindhoven,
the Netherlands
☎00800-74454775




Signify Australia Limited
65 Epping Road, North Ryde,
NSW, 2113 Australia
Toll Free number: 1300 304 404

Signify New Zealand Limited
123 Carlton Gore Road
Newmarket, Auckland 1023
New Zealand
Tel: 0800 454 448

www.philips-hue.com

© 2021 Signify Holding
All rights reserved

4404 029 12662
Last update: 10/2021



Sample set up, add up the wattage of the lights

$$8W + 8W + 8W + 16W = 40W$$

Choose your power supply unit (PSU)

40W PSU: Connect up to 40W of lights and 35 m of cable

100W PSU: Connect up to 100W of lights and 30 m of cable