

PISEN®

**PISEN QUICK Power
Cube 22.5W 10000mAh
Power bank
(TP-D183)**

User Manual

Thanks for purchasing the Pisen power bank. Please read this manual thoroughly to ensure safe and optimal use. Keep it handy for future reference. This product can be used to charge phones and other devices with a DC input.

Specifications

Name	PISEN QUICK Power Cube 22.5W 10000mAh Power bank
Model	TP-D183
Input	Type-C: 5V=3A 9V=2A 12V=1.5A
Output	USB-A1/A2: 5V=3A 9V=2A 10V=2.25A 12V=1.5A Type-C: 5V=3A 9V=2.22A 12V=1.5A Multiple ports output at the same time: 5V=3A MAX Maximum Power: 22.5W
Battery Energy	10000mAh/37Wh
Rated Capacity	5800mAh(2A)
Dimensions	147.5*68.5*17mm (5.8*2.7*0.67 in)

PISEN®

Designed by Pisen Made in China
Manufactured by :Guangdong PISEN Electronics Co., Ltd.
Address:Building 5, 1st Floor, No. 9, Qinfu 1st Street,
Liuyue Nan Community, Henggang Town, Longgang
District, Shenzhen City, Guangdong Province, China

PISEN® The brand belongs to Guangdong PISEN Electronics Co., Ltd.

For FAQs and additional support, visit:
<https://en.pisengroup.com>

Contact: support@pisengroup.com




Weight	Approx. 220g (7.76oz)
Working Temperature	-10°C~35°C (14°F~95°F)
Charging Time	Approx. 2-4 hours(18W charger)

*An 18W charger typically refers to a DC charger with a 9V/2A output.

*Note: The charger is sold separately and is not included with the product.

Product interface diagram



Safety Note:

To ensure safe operation, the device will automatically activate over-temperature protection and shut down output if:

- The main control IC temperature exceeds 120°C, or
 - The battery temperature exceeds 60°C (±5°C).
- Normal operation will resume once temperatures return to safe levels.

Operating Instructions:

- Press the button to initiate charging.
- During active charging, press and hold the button for 3-5 seconds to switch to low-current mode.
- Press and hold again for 3-5 seconds to exit low-current mode and resume normal charging.

Notice

- Do not expose the power bank to direct sunlight.
- Do not throw, squeeze, or disassemble the power bank yourself.
- Avoid using or storing the power bank in overheated or humid environments.
- Never throw the power bank into fire, water, or any corrosive liquid.
- Always use a voltage within the specified range to charge the power bank.
- Do not use the power bank when it is wet.
- Operate and store the power bank within a temperature range of 0°C - 35°C.
- Do not place the power bank on flammable items like textiles or carpets.
- There is an explosion risk if you attempt to disassemble the power bank by yourself.
- Immediately stop using the power bank if it swells or malfunctions.