

TV Mount / TV Stand User Manual

Product Introduction

This TV mount/stand is made of high-strength material with stable structure, reliable load-bearing, easy installation and adjustable angle. Suitable for tabletop or wall-mounted use, safe and space-saving.

Scope of Application

Suitable for LCD TVs, smart TVs, monitors in home, bedroom, office, shop, etc.

Instructions for Use

1. Before installation, confirm TV size and weight **match** the bracket.
2. Fix the backplate/base to the TV firmly with screws.
3. For wall-mounted type: install the mounting plate on **solid wall** with expansion screws.
4. Connect the bracket and mounting plate, ensure locked securely.
5. Adjust tilt or angle as needed, then tighten all screws.

Notes

1. Must be installed by **adults**. Disconnect power before installation.
2. Do not install on weak walls like hollow brick, drywall.
3. Do not **exceed maximum load capacity**.
4. Check stability before use.
5. Avoid impact, pulling or climbing on the TV.
6. Keep children away from the TV and bracket.
7. Check and tighten screws regularly.

Safety Warnings

- Stop using immediately if the bracket is deformed, cracked or loose.
- Arrange cables properly to avoid pinching or pulling.
- Do not place heavy or liquid items on the TV.

Cleaning & Maintenance

1. Wipe with a dry cloth.
2. Do not wash or soak in water.
3. Keep dry to prevent rust.

Troubleshooting

- Loose bracket: Retighten all screws.
- TV tilts: Adjust level and angle.
- Unstable installation: Reinforce the wall or change position.