

## Introduction

Thank you for purchasing the 10 ft. x 10 ft. Pop-Up Canopy. This manual is designed to help you set up, maintain, and care for your canopy to ensure long-lasting use and enjoyment. Please read the instructions carefully before assembly.

## Assembly Instructions

### Unbox and Lay Out Parts

Carefully remove all parts from the box. Ensure all parts are accounted for. Refer to the Parts List at the end of the manual to verify each component.

### Assemble the Frame

Place the canopy frame on a flat, stable surface.

Connect the frame pieces by snapping them together. The frame should lock into place securely.

### Attach the Canopy

Lift the frame to its full height (two people may be required for this step).

Once the frame is elevated, unfold the canopy top.

Secure the canopy top to the frame by attaching the Velcro straps or clips located at the edges of the canopy.

### Secure the Canopy

Use the included stakes or sandbags to secure the canopy to the ground. For optimal stability, place stakes in the corners and use sandbags or weights to ensure the canopy does not blow away in windy conditions.

## Care Instructions

### Cleaning and Maintenance

#### Cleaning the Canopy Fabric

To clean the canopy, gently wipe it down with a damp cloth and mild soap. Avoid harsh chemicals or abrasives.

If the canopy top becomes excessively dirty, it can be hand-washed in cool water with a mild detergent. Allow it to air dry completely before storing.

#### Cleaning the Frame

The frame can be cleaned with a damp cloth or sponge. Dry thoroughly before storage to avoid rust formation.

### Storage Instructions

Always store the canopy in a dry, cool place when not in use. Avoid storing it in direct sunlight to prevent fabric fading.

For prolonged storage, disassemble the frame and pack all components back in the original box or a storage bag for easy access.

### Weather Protection

The canopy is designed to provide shade and light protection from the elements. However, it is

not intended to withstand extreme weather conditions (heavy rain, snow, or high winds). Always disassemble and store the canopy in such conditions to prolong its lifespan.

#### Safety Tips

Do not use the canopy in strong winds, thunderstorms, or other extreme weather conditions.

Do not leave the canopy up overnight or unattended in windy conditions.

Ensure the frame is locked into place before use to avoid any instability.