

U-BOAT

ITALO FONTANA



10.000M

PROFONDO



Dear Customer

WE CONGRATULATE YOU ON THE PURCHASE OF THIS U-BOAT MODEL.

IN THIS MANUAL YOU WILL FIND THE INSTRUCTIONS FOR YOUR WATCH.

WE THANK YOU FOR YOUR TRUST AND INVITE YOU TO REGISTER ON OUR OFFICIAL WEBSITE IN THE [U-CLUB](#) SECTION DEDICATED EXCLUSIVELY TO OWNERS/POSSITORS OF U-BOAT PRODUCTS, IN ORDER TO RECEIVE ADDITIONAL ADVANTAGES, AND BE INFORMED ABOUT OFFERS, EVENTS AND NEWS IN PREVIEW.


Automatic

WATCH FUNCTIONS

- A** SCREW-DOWN CROWN
- B** HOURS PIECE
- C** MINUTES PIECE
- D** SECONDS PIECE
- E** UNIDIRECTIONAL BEZEL
- F** AUTOMATIC HELIUM VALVE



Indicative image
Some components may be missing
or arranged in a different position.



POSITION 1
NEUTRAL POSITION

POSITION 2
FIRST CLICK

POSITION 1
NEUTRAL POSITION


Watch operating position, to wind and start the watch unscrew crown **A** and turn it clockwise.

POSITION 2
FIRST CLICK

Pull out crown **A** to bring it to position 2. Rotate crown **A** to set the desired time.

Press and screw crown **A** back into position 1.

Bezel **E** rotates clockwise.



The helium valve **F** has the function of automatically compensating the internal pressure of the watch.



- Your watch will maintain its performance intact for a long time, with the appropriate care.
- We recommend that you have your watch checked every 3-4 years by one of our Authorized Retailers/Authorized Service Centers, to carry out normal maintenance of all mechanical parts and water resistance.
- We also recommend that you contact an Authorized Retailer/Authorized Service Center to replace the strap.
- Avoid leaving your watch in places exposed to strong temperature variations, humidity, sunlight and intense magnetic fields.
- Make sure that your watch is suitable for use in water.
- Always rinse your watch with fresh water after contact with salt water.
- Automatic watches require manual winding after a long period of inactivity.

PASSION AND ENERGY





U-BOAT HEAD OFFICE

Via Pesciatina 751H

Gragnano, Capannori - 55010 Lucca - Italy

Tel: +39 0583 469288 - Fax: +39 0583 462249

www.uboatwatch.com - service@u-boatwatch.com