

Performance Thermal Paste - 10g

Product ID

SILVGREASE10-PRO



**Product may vary from image*

	Feature	Function
1	Cap	• Screw-on Cap to prevent accidental spills
2	Content Window (not shown)	• Shows the remaining Compound in the Syringe
3	Plunger	• Used to dispense the Compound
4	Plastic Spreader	• Used to Spread the Compound where needed

Package Contents

- Thermal Paste Syringe x 1
- Plastic Spreader x 1
- Product Documentation x 1

Requirements

For the latest manuals, product information, technical specifications, declarations of conformance, and SDS please visit: www.StarTech.com/SILVGREASE10-PRO

- Consult the manufacturer's documentation to determine the correct disassembly and application procedure for your specific device before applying the Thermal Compound

Handling

Refer to the online Safety Data Sheet (SDS) for proper handling, storage, and emergency procedures.

Application

1 Before application, thoroughly **Clean** the **Contact Surface**



2 Apply a **Small** amount of **Thermal Paste**



3 Evenly **Spread** the **Thermal Paste** on the **Contact Surface**, creating a **Thin** and **Uniform Layer**, avoiding **Air Bubbles**



HQ Contact:

StarTech.com Ltd.
45 Artisans Crescent,
London, ON N5V 5E9,
Canada

US Contact:

StarTech.com USA LLP
4490 South Hamilton Rd,
Groveport, OH 43125,
United States

UK Contact:

StarTech.com Ltd.
15 Gowerton Rd,
Northampton, NN4 7BW,
United Kingdom

EU Contact:

StarTech.com Ltd.
Siriusdreef 17-27
2132 WT Hoofddorp
The Netherlands

JP Contact:

StarTech.com K.K.
Atelier Yours Ogawamachi 7F
1-10-2 Kanda Ogawamachi
Chiyoda-ku, Tokyo 101-0052
Japan

FR: startech.com/fr
DE: startech.com/de
ES: startech.com/es
NL: startech.com/nl
IT: startech.com/it
JP: startech.com/jp