

AM 3000 PRO - DOT

Step 5: Insert the new fog light.
Firmly connect the new fog light connector, both male and female connectors are provided for easy installation. Should the old connector be damaged, please replace with new connector.

Step 6: Insert the bolt to fix fog light housing or bezel.
Use the threaded washer and nut to tighten the fog lamp with a ratchet or wrench. Do not over tighten as you may damage the fog light housing or bezel. The housing/bezel should be snug and securely fastened.

Step 7: Re-connect the switch.
Reconnect the fog light switch using the harness clip. The new fog light should now be functional.

Step 8: Turn On the ignition and aim your lights.
Test your new lights. Ensure that the angle is good for visibility and wide angle view. The fog lamp should light up the lower extremities showing the edge of the road surface.

⚠ WARNING:

- Do not touch the lights or the optic lens directly with your bare hands.
- Be sure that the car is completely turned off before installing new lights.
- Above installation steps are a general guide and for reference only, different vehicle models may have different disassembly requirements.



12V LED LIGHTING - 5500K

AM 3000 PRO - DOT

Suitable for Car Fog Lamp Fitment



**100
watts**

**5500
Kelvin**

**7000
Lumens**

**Superior
Brightness**

Enjoy it.

AM 3000 PRO - DOT

Experience a whole new dimension in brightness!

This fog light uses uniform light guide optics while setting the standard with its broad beam angle, guaranteeing a wider field of vision and greatly improved visibility in poor weather conditions.

This fog light is the perfect replacement for most car models. The fog light is compatible with 12-volt automotive electrical systems and provides a bright and efficient LED light of 5,500 Kelvin. Thanks to the plug & play installation the replacement of your existing fog lights is made very easy.

These fog lights come with detailed instructions on how to install them and are designed for those with little to no wiring experience. Installing fog lights will be different on every car model. Follow these general steps as a guide to get started.

AM 3000 PRO - DOT Specification

- | | |
|----------------------------------|---|
| • Voltage: DC 12V | • CANBUS - Intelligent communication protocol capable |
| • Power: 50W each LED lamp | • IP68-Water resistant |
| • Lumens: 7000LM | • Compact design for better fit |
| • Lens size: 3" (76.2mm) | • Energy Saving, Quick start |
| • Lamp Material: Aluminum Alloy | • Superior Brightness |
| • High Power advanced Chipset | • 18 Months Warranty |
| • Color Temperature: 5500 Kelvin | |
| • Up to 180% More Light | |

AM 3000 PRO - DOT

AM 3000 PRO - DOT Installation

Important Safety Information:
Please read this manual before installing and using the LED fog light. Failure to follow these instructions may result in damage to the product or your vehicle and could be a safety hazard.

Step 1: Make sure your vehicle is parked and turned off.
Locate the vehicle on a level surface. Engage the parking brake.

Step 2: Disconnect the fog light switch.
This disconnects the old fog light from the vehicle's power system. It should be disconnected by detaching the harness clip.

Step 3: Remove the nut / threaded washer and if necessary the bolt used to fix the old fog light housing or bezel. This will allow you to remove the fog light housing or the outer bezel.
Make sure to keep all removed parts safely until installation is complete.

Step 4: Remove the old fog light.
Unplug the connector of the existing fog light. Take care not to scratch the bumper or body panels while removing the old fog light

BPIN Private Limited
148 Jolly Maker Chamber No. II, 225 Nariman Point, Mumbai - 400 021. Maharashtra. India.
1800 209 6820 | support@blaupunktcar.in | www.blaupunktcar.in