


POP UP IN DESK UNIT


1 CUT OUT

Determine desired orientation of product and cut hole.




2 INSERT PRODUCT

Fold clamps into provision within housing. Align housing in the cut out and insert housing into desk.




3 TIGHTEN SCREWS

Screw through the plastic housing and clamps so that they rotate out of the housing. Tighten screws until the assembly clamps down and is secure. The clamps will grip into underside of desk. **DO NOT OVER TIGHTEN - TIGHTEN BY HAND ONLY.**




4 CLIP ON COVER

Align clips on the underside of the cover with provisions in housing. Secure the top cover and push down above where the clips are positioned.



5 CONNECT TO POWER

Plug into power source



Available Power Outlets

