



# 1080P HD Webcam

## User Manual



Model: AWC201-B

## **Thank you for purchasing an Amcrest Webcam!**

We wanted to personally reach out and thank you for purchasing from our Amazon store. Selling on Amazon is what we do to support our family, and product reviews are the lifeblood of our business. It would mean the world to us if you could take one minute of your time to help share the love by leaving us an honest review using the link below:

[www.amazon.com/ryp](http://www.amazon.com/ryp)

Thank you again for being one of our amazing customers!

Sincerely,

Amcrest Team

### Product Overview

**Thank you for purchasing an Amcrest Webcam!**

This guide is designed to help you setup and better use your Amcrest webcam. If you have questions before you start or just want to learn more about Amcrest, please visit us at: [amcrest.com](http://amcrest.com)



1. 1080P HD Lens
2. Microphone
3. Activity LEDs
4. Flexible Clip/base
5. Tripod Attachment
6. Privacy Cover


## Setting Up Your Webcam

### 1. Placing Your Webcam

The webcam has a rotatable clip base which allows the device to be secured to a monitor, or desktop, or tripod.


#### Placement on a Monitor

- Grasp the webcam, as displayed in the image below, and open the clip base.
- Place the opened clip base onto the monitor making sure the foot of the clip base is flush with the back of the monitor.



### Placement on a Desktop


- Close the base of the clip and place it on your desktop.




### Placement on a Tripod

The webcam is equipped with a standard female 1/4" tripod screw on the base of the clip which allows the camera to be placed on the included stand or a separately purchased tripod.

Place the tripod screw on the male end of the stand or tripod and twist the base allowing it to be secure to the stand/tripod.



## 2. Connecting the Webcam



The webcam is compatible with both Windows and Mac computers. To setup your webcam, plug the USB cord of the webcam into a USB plug on your device.

The webcam will begin to install automatically on your device. Allow the webcam about 1 minute to finish installing before attempting to access.

**Note:** The webcam does not require the use of additional software to function. All adjustments to quality or other settings will be performed via the third party software that is being used to view your camera.

### Video Calling



**Your Amcrest HD Webcam provides full HD 1080P video calling.**



To take advantage of video calling both you and the person you are calling must install Skype™ or other similar video-calling applications such as Microsoft Teams, Gmail, or any other platforms that support video calling.

As well as needing a webcam and video calling application, both callers need:


- A computer with speakers (or headset) and a microphone; your Amcrest HD webcam has a built-in microphone.
- An internet connection/computer capable of handling 1080P video streaming and audio.

## Frequently Asked Questions

### 1. How do I know if the webcam is recognized or installed on my computer?


Once the webcam has been connected to your device, it will take approximately 1 minute for the webcam to be automatically recognized or installed.

To verify connectivity on Windows, go to Control Panel> System and Security>System>Device Manager>Sound, video controllers>HD Webcam USB.




## Amcrest Pro HD Webcam

You can also verify connectivity by going to Computer Management>Device Manager>Sound, Video Controllers>HD Webcam USB. Double click to verify.



To verify connectivity on Mac, go to Finder>Applications>Photo Booth.



### **2. How do I know if the video call application is using my webcam?**

This can be verified in the video calling application directly. Open the video calling application, typically if the webcam is being used by the software the live feed from the webcam will show. If it does not show, you can verify your camera settings in the settings menu of your video calling application.

### **3. Why is my camera having issues when I try to use it in Skype, Facebook, and other applications?**

Most software will automatically display the webcam by default if it is properly connected to your computer. If your camera is not showing, verify your camera is properly connected or go to the video settings of the software you are using and make sure the proper camera is selected.

For instance, if you are using Skype, you can go to Settings>Audio&Video to enable the HD Webcam USB via the available drop down box located on the screen. The same concept can apply to most other third party software if similar issues are occurring.

HD Webcam USB




#### **4. Why does the microphone still not work even though it is being recognized by my computer?**

This could mean there is communication issue happening between the camera and your computer. This can be resolved by uninstalling and then reinstalling the webcam.

On your computer, navigate to Computer Management>Device Manager>Sound, video and game controllers and click to expand the menu. Locate the HD Webcam USB option, right click and select "Uninstall device".

## Amcrest Pro HD Webcam

---



Once the webcam has been uninstalled, unplug the USB cord from your computer and then plug it back into the USB port. The webcam will automatically install the new driver. Wait about 1 minute and verify if the microphone is working properly.

The audio settings can also be adjusted in the settings menu using any third party software.

### 5. Why does the feed from the webcam keep flickering and cutting out on the bottom?

This could be an indication that there is inadequate power being supplied to the webcam. Please try other USB port, such as one on the back of the computer, which gets power from the mainboard of your computer.

### 6. How do I adjust video settings for the webcam?

All video settings and parameters will be controlled by the settings of the third party viewing software being used. Access the webcam settings located in your particular viewing software and configure it according to your specifications.





[www.amcrest.com](http://www.amcrest.com)

© 2020 Amcrest. All rights reserved. Amcrest, the Amcrest logo, and other Amcrest marks are owned by Amcrest and may be registered. Microsoft, Windows, and the Windows logo are trademarks of the Microsoft group of companies. All other trademarks are the property of their respective owners. Amcrest assumes no responsibility for any errors that may appear in this manual. Information contained herein is subject to change without notice.

