


MODULE LIGHT SPEAKER User's Manual


1. Installation



2. Function

The MODULE LIGHT SPEAKER: 1.1 Chroma Speaker (120V/60Hz) plays songs through radio frequencies and Bluetooth modules. Turn on the Bluetooth feature on your phone, and you'll instantly find the ChromaComfort-Sensonic Speaker Bluetooth device and click to connect. Open the music player software on the phone and play the music through the Bluetooth speaker.

Function Description



A. Indicator light

The indicator light will turn on blue when pressed effectively, and will be off when impressed or pressed for more than 16s.

B. Button #1 (for white light)

a. Short press (<1.2s)

A short press for less than 1.2s will turn the white light on/off.

b. Long press ($\geq 1.2s$)

Basic function: to turn the white light on.

Pairing function (within the first 3min after the grille power on):

Press Button #1 for more than 1.2s until the white light on, then grille and wall control get paired successfully.

To cancel the pairing, users need to keep pressing Button #1 for more than 10s, until the white light reaches its highest luminance and gets dim gradually. The white light will flash twice, which means the pairing is cancelled.

If keep pressing Button #1 for more than 5s then, the white light will get lighter and reach its highest luminance. The white light will flash twice, which means the paired again.

*If the white light is not on after a long press of over 1.2s and less than 5s, which means grille and wall control are not paired. Users need to keep pressing for more than 5s until the white light will get lighter and reach its highest luminance, and then grille and wall control get paired successfully. If users keep pressing for more than 10s, the pairing will be cancelled.

*If the white light is not on after a long press of over 5s, which means grille and wall control are already paired. If users keep pressing for more than 10s, the pairing will be cancelled. And if users keep pressing for more than 5s after that, it will start the pairing again.

C. Button #5 (for colored light)

a. Short press (<1.2s)

A short press for less than 1.2s will turn the colored light on/off.

In RGB sweep mode, that can turn off the colored light only. If

turned on again, it will be switched into RGB static mode.

b. Long press ($\geq 1.2s$)

A long press for over 1.2s will turn on the RGB sweep mode.

If it's already in RGB sweep mode, a long press for over 1.2s will turn it off.

D. Button #7 (for fan)

a. Short press ($< 1.2s$)

A short press for less than 1.2s will turn the fan on/off.

b. Long press ($\geq 1.2s$)

A long press for over 1.2s and less than 10s will turn on the fan on/off.

A long press for over 10s until the indicator light flash twice, will cancel the BT connection. 10s later, users can reconnect BT.

E. Button #2 (for decreasing luminance)

a. Short press ($< 1.2s$)

A short press for less than 1.2s will decrease the luminance level by level, but won't turn it off.

b. Long press ($\geq 1.2s$)

A short press for more than 1.2s will decrease the luminance gradually, not level by level, but still won't turn it off.

F. Button #3 (for increasing luminance)

a. Short press ($< 1.2s$)

A short press for less than 1.2s will increase the luminance level by level until the highest luminance.

c. Long press ($\geq 1.2s$)

A short press for more than 1.2s will increase the luminance gradually, not level by level, until the highest luminance.

G. Button #4 (for RGB color inverted change)

a. Short press ($< 1.2s$)

When not in RGB sweep mode, a short press for less than 1.2s will change RGB color in inverted order level by level.

When in RGB sweep mode, a short press for less than 1.2s will stop the RGB sweep mode. At this time, another short press will make it in RGB static mode.

b. Long press ($\geq 1.2s$)

When not in RGB sweep mode, a long press for more than 1.2s will change RGB color in inverted order continuously.

When in RGB sweep mode, a long press for more than 1.2s will stop the RGB sweep mode. At this time, another long press will make RGB static change in inverted order continuously.

H. Button #4 (for RGB color inverted change)

a. Short press ($< 1.2s$)

When not in RGB sweep mode, a short press for less than 1.2s will change RGB static color in sequence level by level.

When in RGB sweep mode, a short press for less than 1.2s will stop the RGB sweep mode. At this time, another short press will make it in RGB static mode.

b. Long press ($\geq 1.2s$)

When not in RGB sweep mode, a long press for more than 1.2s will change RGB color in sequence continuously.

When in RGB sweep mode, a long press for more than 1.2s will stop the RGB sweep mode. At this time, another long press will make RGB static change in sequence continuously.

Remark:

All the functions, except for pairing function, work when grille and wall control paired.

Button #2 and Button #3 work only when light on.

Button #4 and Button #6 work only when colored light on.

The operations should follow certain order mentioned above.

For function details, please refer to ERD.

3. Warning

DISCONNECT POWER AT SERVICE ENTRANCE BEFORE CLEANING OR SERVICING. ADD GRILLE CURRENT TO FAN CURRENT FOR TOTAL CURRENT DRAW. INSTALL ONLY WITH MODELS INDICATED IN THE INSTALLATION INSTRUCTIONS.

COUPEZ L'ALIMENTATION AU PANNEAU ÉLECTRIQUE AVANT LES TRAVAUX DE NETTOYAGE OU D'ENTRETIEN. ADDITIONNEZ LA CONSOMMATION DE COURANT DE LA GRILLE À CELLE DU VENTILATEUR POUR OBTENIR L'APPEL TOTAL DE

COURANT. S'INSTALLE UNIQUEMENT AVEC LES MODÈLES INDIQUÉS DANS LES DIRECTIVES D'INSTALLATION.

FCCWARNING

Any Changes expressly or modifications not approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment .

This transmitter must not be co - located or operating in conjunction with any other antenna or transmitter.

This equipment should be installed and operated with minimum distance 20cm between the radiator & you body.

ISED RSS warning

This device complies with Innovation, Science and Economic Development Canada Compliance-exempt RSS standard (s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Innovation, Sciences et Développement économique Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes:

(1) l'appareil ne doit pas produire de brouillage, et

(2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

ISED Radiation Exposure Statement:

This equipment complies with ISED RF radiation exposure limits set forth for an uncontrolled environment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter. This equipment should be installed and operated with minimum distance of 20 cm between the radiator and your body.

IC exposition aux radiations:

Cet équipement est conforme avec ISED les limites d'exposition aux rayonnements définies pour un contrôlé environnement. Cet émetteur ne doit pas être co-localisés ou fonctionner en conjonction avec une autre antenne ou émetteur. Cet équipement doit être installé et fonctionner à au moins 20 cm de

distance d'un radiateur ou de votre corps.

15B warning

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.