

08KBEAR User Guide

KEEP THIS USER GUIDE FOR FUTURE REFERENCE

Always retain your proof of purchase in case of warranty service.

Keep all packaging materials out of reach of children. Risk of suffocation!



<p>MAIN SWITCH</p>	<p>Power Switch For first time use, insert a paper clip (or similar) into the MAIN SWITCH hole, as indicated in the image to the left.</p>	
	<p>On/Off Press the button to turn the screen and backlight on/off. *Device will automatically wake when the alarm time is reached.</p>	
	<p>Adjust Backlight (7 levels of brightness) Press to increase brightness. Press to decrease brightness.</p>	
	<p>SETTING THE CURRENT TIME Press the button. Make sure that the CURRENT TIME MODE icon is displayed on screen, then press and hold the button for 3 seconds to enter current time setting.</p> <ul style="list-style-type: none"> The HOURS will now begin to flash. Press or to adjust the hour. Press again to set the MINUTE. Press or to adjust the minutes. Press again to confirm the selection. Press again to display Koala face only / Koala face and clock / clock only. 	
	<p>SETTING THE DAYTIME (WAKE-UP TIME) This setting is to determine the time that the MOON icon and Red backlight is replaced by the SUN icon and orange backlight. Press the button. Make sure that the DAYTIME icon is displayed, then press and hold the button for 3 seconds to enter the Daytime setting.</p> <ul style="list-style-type: none"> The HOURS will now begin to flash. Press or to adjust the hour. Press again to set the MINUTE. Press or to adjust the minutes. Press again to confirm the selection. Press again to display Koala face only / Koala face and clock / clock only. <p><i>Note: The DAYTIME can be set between 04:00 AM ~ 02:59 PM. Press and hold and buttons for 3 seconds to reset to default setting (06:00 AM)</i></p>	
<p>ACTIVATED / DEACTIVATED ALARM The Alarm clock can be activated / deactivated when setting the DAYTIME. Make sure the daytime icon is displayed and the hours / minutes is flashing. • Press the button to activate / deactivate the alarm setting. When the alarm is activated, a bell icon will appear on the display. <i>Note: When the alarm is activated, it can be deactivated by pressing one of the control buttons. If it is not turned off it will alarm for a maximum of 1 minute.</i></p>		
	<p>SETTING THE NIGHTTIME (SLEEP TIME) This setting is to determine when the backlight will change from orange to red. Press button, make sure that the NIGHTTIME icon is displayed. Press and hold the button for 3 seconds to enter NIGHTTIME setting.</p> <ul style="list-style-type: none"> The HOURS will now begin to flash. Press or to adjust the hour. Press again to set the MINUTE. Press or to adjust the minutes. Press again to confirm. Press again to display Koala face only / Koala face and clock / clock only. <p><i>Note: The Nighttime can be set between 03:00 PM and 03:59 AM. Press and hold and buttons for 3 seconds to reset default setting (6:00 PM)</i></p>	
	<p>Display modes Press at anytime to select between the following display options: Koala only / Koala and time / time only.</p>	
	<p>Reset To reset to default settings (except current clock setting), press and hold all three buttons at once: + + until CLR appears on the display.</p>	
	<p>Lock Lock clock to prevent settings from being accidentally changed. Press and hold and buttons for 5 seconds to Lock / Unlock. When locked, a key icon will appear on the display.</p>	
	<p>Low Battery Alert When battery becomes low, the battery icon will appear on the display. Also, when the battery is low, the backlight will be turned off automatically to save battery power. Tip: When not in use for an extended period, charging every two months will help protect the life of the lithium battery.</p>	

Specifications: USB power adaptor: 5V 500mA (not supplied), Battery: 3.7V 500mAh Lithium-ion, Charge time: 2-3 Hours fully charged

Warnings: • For your continued safety and the reliability of your clock, please observe normal electrical safety precautions.

- This product is not a toy, keep out of reach of children. Rechargeable Lithium-ion batteries are potentially hazardous and can present a serious fire hazard if damaged, defective or improperly used. Do not leave your product unattended whilst charging the battery.
- Keep the product away from water and moisture. It's intended for indoor use only.
- This product does not include any user serviceable parts. DO NOT DISASSEMBLE THIS PRODUCT.
- Dispose of this product which includes a lithium-ion battery in accordance with local disposal waste regulations.

Express Warranty (Australia)

This Express Warranty is provided by Oricom International Pty Ltd ABN 46 086 116 369, Unit 1, 4 Sovereign Place, South Windsor NSW 2756, herein after referred to as "Oricom".

Oricom warrants that the product is free from defects in materials or workmanship during the Express Warranty Period. This Express Warranty does not extend to any product from which the serial number has been removed or was purchased outside of Australia.

The benefits of this Express Warranty are in addition to other rights and remedies you may have under the Australian Consumer Law. Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure. In the event of a minor failure, Oricom reserves the right to choose to repair or replace the product.

The Express Warranty Period will be a period of 12 months beginning on the date of purchase of the product evidenced by your dated sales receipt. You are required to provide proof of purchase as a condition of receiving Express Warranty services.

You are entitled to a replacement product or repair of the product at our discretion according to the terms and conditions of this document if your product is found to be faulty within the Express Warranty Period. This Express Warranty extends to the original purchaser only and is not transferable.

Products distributed by Oricom are manufactured using new materials or new and used materials equivalent to new in performance and reliability. Spare parts may be new or equivalent to new. Spare parts are warranted to be free from defects in material or workmanship for thirty (30) days or for the remainder of the Express Warranty Period of the Oricom branded product in which they are installed, whichever is longer. During the Express Warranty Period, Oricom will where possible repair and if not replace the faulty product or part thereof. All component parts removed under this Express Warranty become the property of Oricom. In the unlikely event that your Oricom product has a recurring failure, Oricom may always, subject to the Competition and Consumer Act 2010, at its discretion, elect to provide you with a replacement product of its choosing that is at least equivalent to your product in performance.

No change to the conditions of this Express Warranty is valid unless it is made in writing and signed by an authorised representative of Oricom.

Oricom will not be liable under this Express Warranty, and to the extent permitted by law will not be liable for any defect, loss, damage or injury arising out of or in connection with a:

1. Failure by you to adhere to the warnings and follow the instructions set out in this user guide for the proper installation and use of the product;
2. Willful misconduct or deliberate misuse by you of the product;
3. Any external cause beyond our control, including but not limited to power failure, lightning or over voltage; or
4. Modification to the product or services carried out on the product by anyone other than Oricom or Oricom's authorised service provider.

How to make a claim under your Express Warranty in Australia

Oricom has a simple warranty process for you to follow:

- Please call or email our Customer Support Team, 02 4574 8888 or support@oricom.com.au.
- A Customer Support Team member will verify after troubleshooting with you if your product qualifies under warranty. If so, they will give you a Product Return Authorisation number.
- We will then email a Return Authorisation form and a Repair Notice (if necessary), together with instructions on how to return the product for warranty service.

Please note that if a Customer Support Team member advises that your product does not qualify for return, this warranty does not apply to your product. Products that are authorised to be returned to Oricom in Australia must include all of the following:

- A completed Return Authorisation form
- A copy of your Proof of Purchase (please keep your original copy)
- The faulty product, including all accessories.

Send the approved returns to:

Oricom International Pty Ltd
Locked Bag 658
South Windsor NSW 2756 Australia

Please note that this Express Warranty excludes expenses incurred by you in returning any faulty product to us. You must arrange and pay any expenses incurred (including postage, delivery, freight, transportation or insurance of the product) to return the faulty product to us, however, we will arrange delivery of the repaired or replaced faulty product to you.

Important Information - Repair Notice

Please be aware that the repair of your products may result in the loss of any user-generated data (such as stored telephone numbers, text messages and contact information). Please ensure that you have made a copy of any data saved on your product before sending for repair. Please also be aware that products presented for repair may be replaced by refurbished products or parts of the same type rather than being repaired.

ORICOM CUSTOMER SUPPORT

Oricom have a trained and dedicated team of Customer Support Representatives, each with the knowledge and resources to assist in answering your questions quickly and efficiently.

Oricom Support - Australia

For all product enquiries, troubleshooting or to discuss the range of Oricom products, feel free to contact Oricom or visit our website for answers to frequently asked questions.

02 4574 8888
Monday - Friday 8am – 6pm AEST
Email: support@oricom.com.au
www.oricom.com.au

Oricom Support - New Zealand

0800 674 266
Monday - Friday 10am - 8pm NZST
Email: support@oricom.co.nz

oricom®