

SKMEI 1155B Digital Watch Instruction




A. Features:


1. 12 Digits LCD display, display Hour, Minute, Second, Month, Day and Week
2. Daily Alarm and Chime Hourly
3. 12/24H format selectable, auto calendar
4. 1/100 second chronograph with split function
5. EL backlight

B. Operational Manual

- At any mode, press A key then EL backlight will last for 3s.
- Press B key to convert mode:



Chronograph Function:



Alarm Setting:

- In normal time display mode, press B key twice enter into alarm mode and press C key then "Hours" flashing.
- Press D key to adjust "Hours" for your alarm. Pay attention to AM/PM, 12H display A/P means AM/PM. 24H display "H" only means Hour.

- Press C key then "Minutes" flashing, press D key to adjust "Minutes" for your alarm. Press B key to exit.

Alarm & Chime ON/OFF:

- In normal time display mode, press B key twice enter into alarm mode, press D key to turn on/off the Alarm&Chime function.
- If just alarm (🔔 / 🕒 / 🔄 / 🕒 / 🕒 / 🕒 / 🕒 / 🕒) / AL / AL / ALM / ALARM / chime (🔔 / 🕒 / 🔄 / 🕒 / 🕒 / 🕒 / 🕒 / 🕒) / SIG CH CHU CHM CHIME symbol appear, means alarm and chime function ON, otherwise means OFF.

Time & Date Setting:

- In normal time display mode, press B key three times to enter setting mode and the "Seconds" flashing. Press D key to reset the seconds to zero.
- Press C key the "Hour" will flash, press D key to adjust "Hours" once Hour reach 12/24 digit, it will automatically convert 12/24H mode.
- Press C key the "Minute" will flash, press D key to adjust the correct "Minutes".
- Press C key the "Date" will flash, press D key to adjust the correct "Date".
- Press C key the "Month" will flash, press D key to adjust the correct "Month".
- Press C key the "Week" will flash, press D key to adjust the correct "Week".
- Press B key to exit.