




12MP IMX477 HQ Camera Board with Tripod Mount for Raspberry Pi

SKU: B024001



QUICK START GUIDE
High Quality Camera Board

This Arducam IMX477 High-Quality Camera board is designed for Raspberry Pi, no lens is included in this product, and we recommend you use a C- or CS-mount lens with it.

SETUP

● Fitting the lens

1. Identify your lens mount Type

You should prepare a lens for this camera board. 3 kinds of lenses are used most for embedded cameras - M12 lens, C-Mount Lens, and CS-Mount Lens. Make sure which kind of lens you are using before proceeding.

2. For CS-Mount Lens

CS-mount is the stock mount of this camera module, and it won't focus properly if any other adapter is fitted, so remove it if there is one. Then rotate the CS-Mount lens into the CS camera mount.

3. For C-Mount Lens

Thread the C-CS adapter that comes with the lens first. C-mount lens has a longer back focus length, and therefore requires the adapter. Then rotate the C-Mount Lens into the C-CS adapter.


4. For M12 Lens

Thread the M12-CS adapter that comes with the lens first. Then rotate the M12 Lens into the M12-CS adapter.

CONNECT THE CAMERA

You need to connect the camera module to the Raspberry Pi's camera port.

- 1 Locate the camera port near the USB C power connector, and gently pull up on the plastic edge.
- 2 Push in the camera ribbon and make sure the silver connector is facing the Raspberry Pi camera MIPI port. Do not bend the flex cable and make sure it is firmly inserted.
- 3 Push the plastic connector down while holding the flex cable until the connector is back in place.



SPECS

Size: 38 x 38 x 18.4mm (excluding lens)

Still resolution: 12.3 Megapixels

Video modes: Video modes: 1080p30, 720p60 and 640 × 480p60/90

Linux integration: V4L2 driver available

Sensor: Sony IMX477

Sensor resolution: 4056 x 3040 pixels

Sensor image area: 6.287mm x 4.712 mm (7.9mm diagonal)

Pixel size: 1.55 µm x 1.55 µm

IR Sensitivity: Visible light Interface: 2-lane MIPI CSI-2

Default Lens Mount: CS-Mount

Hole Pitch: Compatible with 29mm, 30mm, 34mm

SOFTWARE SETTING

Please make sure you are running the latest version of Raspberry Pi OS. (January 28th 2022 or later releases, Debian version: 11 (bullseye)).

For Raspbian Bullseye users, please do the following:

1. Edit the configuration file: `sudo nano /boot/config.txt`
2. Find the line: `camera_auto_detect=1`, update it to:
`camera_auto_detect=0`
`dtoverlay=imx477`
3. Save and reboot.

For Bullseye users running on Pi 0-3, please also:

1. Open a terminal
2. Run `sudo rasp-config`
3. Navigate to *Advanced Options*
4. Enable *Glamor graphic acceleration*
5. Reboot your Pi.

OPERATING THE CAMERA

`libcamera-still` is an advanced command line tool for capturing still images with the IMX477 Camera Module.

```
libcamera-still -t 5000 -o test.jpg
```

This command will give you a live preview of the camera module, and after 5 seconds, the camera will capture a single still image. The image will be stored in your home folder and named `test.jpg`.

`-t 5000`: Live preview for 5 seconds.

`-o test.jpg`: take a picture after the preview is over and save it as `test.jpg`

If you only want to see the live preview, use the following command:

```
libcamera-still -t 0
```

Note:

This camera module supports the latest Raspberry Pi OS Bullseye (released on Jan 28th, 2022) and `libcamera` apps, not for the previous Raspberry Pi OS (Legacy) users.

FURTHER INFORMATION

For further information, check the following link:

<https://www.arducam.com/docs/cameras-for-raspber-ry-pi/raspberry-pi-libcamera-guide/>

COPYRIGHT

Specifications are subject to change without notice. No part of the specifications may be reproduced in any form or by any means or used to make any derivative such as translation, transformation, or adaptation without permission from Arducam. All rights reserved.

CONTACT US

Email: support@arducam.com

Forum: <https://www.arducam.com/forums/>

Skype: arducam