

## SETUP REQUIRES:

- Weather display with wireless charging pad
- Power Adapter (2 x AA backup batteries recommended)
- Temperature & Humidity Sensor
- 2 x AA alkaline or lithium batteries for sensor (not included)

### 1 INSTALL SENSOR BATTERIES

### 2 PLUG IN DISPLAY WITH THE POWER ADAPTER, AND INSTALL BACKUP BATTERIES (optional, recommended).

### 3 CONFIGURE DISPLAY SETTINGS BY USING THE ARROWS TO CHANGE A SETTING AND PRESSING "SET" TO SAVE AND CONTINUE TO THE NEXT SETTING.


- Clock Hour/Minute
- Month/Day/Year
- Units Preference (\*F/\*C)

You can edit your settings at any time by pressing the "SET" button.

### 4 PLACE SENSOR OUTSIDE


Hang the sensor in a suitable location, like a well-covered tree branch, by using the integrated hang holes or string (string not included).

- At least 5 feet (1.5 meters) off the ground
- Out of direct sunlight
- Away from heat and humidity sources
- Within 165 feet (50 meters) of display



## ONLINE PRODUCT REGISTRATION

Register your product online within 30 days from the date of purchase at [www.acurite.com/product-registration](http://www.acurite.com/product-registration)



## WEATHER FORECAST LEARNING MODE

The Self-Calibrating Forecast uses a unique algorithm to analyze changes in pressure over a time period (called Learning Mode) to determine your altitude. After 14 days, the self-calibrated pressure is tuned in to your location and the unit is ready for superior weather prediction.

## SET ALARM CLOCK

1. Press and hold the "ALARM" button until the Alarm time flashes.
2. Adjust the alarm hour and minute using the up/down arrows, pressing "SET" to save and continue.

## TURN ALARM CLOCK ON OR OFF

Press the "ALARM" button once to turn the alarm on or off. When alarm is turned on, the screen will flash the currently set alarm time for 3 seconds.

## ADJUST DISPLAY BRIGHTNESS

Press the "SNOOZE / LIGHT" button to adjust the brightness off the screen, or to set to auto-dimming at night.

## WIRELESSLY CHARGE PHONE OR SMARTWATCH

This Weather Display with charging pad is Qi Certified. Products marked as Qi Certified have passed rigorous, independent laboratory tests for safety, interoperability and energy efficiency. This wireless charging pad will deliver a safe and reliable wireless charging experience.

For phones and watches able to be charged wirelessly, place your device on the wireless charging pad with the charging location lined up, and confirm your device begins to charge. A charging icon will also appear on the weather display.

\*NOTE: Weather display must be powered by power adapter to use wireless charging.

## TROUBLESHOOTING

Problem	Possible Solution
No outdoor data on the display	Verify the sensor is powered on and in range of the display. The sensor must be within 165 feet (50 meters) of the display, but certain housing construction materials or environmental factors may impact the working range of the signal.
Time, date, or units of measurement need to be adjusted.	On the display, press the "SET" button at any time and use the up/down arrows to adjust the display settings. Use the "SET" button to save and toggle to the next settings. If no buttons are pressed for 8 seconds, the display will save and exit setting mode.
Phone or smartwatch not charging	<ul style="list-style-type: none"> <li>• Verify the charging pad is powered by the included power adapter. Device will not charge while powered by backup batteries alone.</li> <li>• Verify the charging area of your device is lined up with the wireless charging pad on the display.</li> <li>• Verify your phone and phone case are compatible with wireless charging. Some phone cases do not allow wireless charging. Refer to your device's manufacturer for more information.</li> </ul>

### FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

### Caution!

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

### Canada Statement

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:

- (1) This device may not cause interference.
- (2) This device must accept any interference, including interference that may cause undesired operation of the device.

L'émetteur/récepteur exempt de licence contenu dans le présent appareil est conforme aux CNR d'Innovation, Sciences et Développement économique Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes :

- 1) L'appareil ne doit pas produire de brouillage;
- 2) L'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

The device meets the exemption from the routine evaluation limits in section 2.5 of RSS 102 and compliance with RSS-102 RF exposure, users can obtain Canadian information on RF exposure and compliance.

Le dispositif rencontre l'exemption des limites courantes d'évaluation dans la section 2.5 de RSS 102 et la conformité à l'exposition de RSS-102 rf, utilisateurs peut obtenir l'information canadienne sur l'exposition et la conformité de rf.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter. This equipment should be installed and operated with a minimum distance of 10 centimeters between the radiator and your body.

Cet émetteur ne doit pas être Co-placé ou ne fonctionnant en même temps qu'aucune autre antenne ou émetteur. Cet équipement devrait être installé et actionné avec une distance minimum de 10 centimètres entre le radiateur et votre corps.

### Part 18

The interference potential of the device could cause the interference to the system whose fundamental is 110 KHz to 148 KHz. This device complies with Part 18 of the FCC Rules. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Increase the separation between the equipment and any other radio device.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

The device prevent from using with damping environment. Use only in according with described instruction in order not to damage the device.

### FCC Radiation Exposure Statement

This device complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment must be installed and operated in accordance with provided instructions and the antenna(s) used for this transmitter must be installed to provide a separation distance of at least 15 cm from all persons.



# ACURITE®

## Quick Setup Guide 01193M

**WE'RE HERE TO HELP!**

When you have questions or need assistance, visit us online at [www.acurite.com/support](http://www.acurite.com/support)

**LIMITED 1-YEAR WARRANTY.**

For more information on warranty and other policies, visit us online at [www.acurite.com/warranty](http://www.acurite.com/warranty).

