



Operating Instructions

107cm Evaporative Tower Fan



Model: GCEV200

READ ME FIRST

Evaporative Cooler

Please read these instructions & user manual carefully.

It is important to note that Evaporative Coolers are fans that pass the room air through a filter that has water pumped over it in order to create a cooler air flow.

You can add ice to the water to help cool the air more but there is no refrigeration system in the unit so the water in the tank will eventually come up to room temperature.

Unlike a portable air conditioner, it will not expel the hot air from the room so will not dramatically bring the air temperature in the room down.

Do not place the unit in wardrobes or other enclosed spaces as this may cause a fire hazard.

It is recommended that this appliance is plugged directly into the wall socket. Power boards are not rated to supply power to high wattage appliances.

A correctly specified, undamaged extension cord may be used with this Evaporative Cooler provided it is used in a safe manner.

Do not dispose of packaging until completely satisfied with your purchase.

Please refer to your user manual for operating instructions, further information or trouble shooting before you call the Customer Service number listed within the user manual.

General Care and Safety Guide

Thank you for choosing this Goldair product. This Goldair appliance has been designed and manufactured to high standards of engineering and with proper use and care, as described in this leaflet, will give you years of useful service. Please read these instructions carefully and keep them for future reference.



1. This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
2. Children should be supervised to ensure that they do not play with the appliance.
3. If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.
4. Ensure that the fan is switched off from the supply mains before removing the guard.
5. Use only the voltage specified on the rating plate of the appliance.
6. Keep all objects at least 1 Metre from the front, sides and rear of the appliance
7. This appliance is intended for household use only and not for commercial or industrial use.
8. Use this appliance only as described in this manual. Any other use is not recommended by the manufacturer and may cause fire, electric shock or injury.
9. The common cause of overheating is deposits of dust or fluff in the appliance. Ensure these deposits are removed regularly by unplugging the appliance and vacuum cleaning the air vents and grills.
10. Always unplug appliance when not in use.
11. When the appliance has been unpacked, check it for transport damage and ensure all parts have been delivered. If parts are missing or the appliance has been damaged, contact the Goldair Customer Services Team.
12. If your appliance does not work, or is not working properly, contact the place of purchase. Repair work on the appliance by unqualified persons can cause serious risk to the user.
13. Ensure hands are dry before handling the plug or the main unit.
14. Carry out regular checks of the supply cord to ensure no damage is evident.
15. Ensure that the cord is fully extended (not coiled) while in use.
16. Avoid contact with the moving parts. Keep hands, hair, clothing, away from blade of the fan during operation to reduce the risk of injury to person and/or damage to the unit.
17. Switch off and use handles provided when moving.
18. It is recommended that this fan is plugged directly into the wall socket.
19. A correctly specified, undamaged extension cord may be used with this fan provided it is used in a safe manner.

General Care and Safety Guide

20. Never place appliance close to radiant heat source.
21. Never operate in areas where petrol, paint or other flammable liquids are used or stored.
22. Never use the appliance to dry clothes.
23. Never insert or allow foreign objects to enter any ventilation or exhaust opening, as this may cause an electric shock, fire or damage to the appliance.
24. Never use abrasive cleaning products on this appliance. Clean with a damp cloth (not wet) rinsed in hot soapy water only. Always remove plug from the mains supply before cleaning.
25. Never connect the appliance to mains supply until completely assembled and adjusted.
26. Never remove plug from power socket until the appliance has been switched off.
27. Never remove plug from power socket by pulling cord – always grip plug.
28. Never twist, kink or wrap the cord around the appliance, as this may cause the insulation to weaken and split. Always ensure that all cord has been removed from any cord storage area and is unrolled before use.
29. Never use this appliance in the immediate surrounds of a bath, a shower, or a swimming pool or other liquids. The appliance must not be immersed in any liquids.
30. Due to the risk of injury, never use this appliance for any purpose other than its intended use. This appliance is intended for use in household and similar applications such as staff kitchen areas in shops, offices and other working environments; farm houses, by clients in hotels, motels, bed and breakfast type environments and other residential type environments
31. Never use this appliance outdoors.
32. Never operate the appliance with a damaged cord or plug, after it malfunctions, or if it has been damaged in any manner. Have the appliance checked and repaired by a qualified electrician if repair is necessary.
33. Never place the unit in wardrobes or other enclosed spaces as this may cause fire hazards.




Components






Assembly

1. Assemble the base. (Figure 1)
2. Align the holes on the air cooler's body. (Figure 2-3)
3. Press the spring button at the bottom of the air cooler's body and rotate the base to the right until it fits in the groove. (Figure 4)
4. Release the spring button at the bottom of the air cooler's body and check the stability. (Figure 5)



Spring Button



Operating your Fan

Always choose a safe location for the appliance, keeping in mind the safety precautions outlined. Ensure all packaging has been removed from the appliance before use. This appliance requires no installation, it should be used solely as a portable appliance.

WARNING: keep all objects at least 1 metre from the front, sides and rear of the appliance.

- For best operating performance, position the appliance in a location that will create a 'flow through' air effect. The greatest cooling effect will be felt if the appliance is operated in a partly opened doorway or window with the "cool" conditioned air directed into the room to be cooled.
- It is important to also have a door or window partly opened away from the cooler to create this 'flow through' effect.
- On days of high humidity, the cooling effect may be reduced as the air entering the filter may already be saturated with moisture. On days like this it may be better to switch the cooling feature OFF and operate the appliance as a fan only.

IMPORTANT NOTE: This appliance does not have a refrigeration unit to keep the water cold, and the water will warm up to ambient room temperature if you don't keep adding ice or pre-frozen Ice Packs.

Filling water tank

- Pull the water tank lock upward to unlock it.
- Carefully pull out the water tank until the interior is visible.
- Pour clean cold water into the water tank, observing the water level indicator in the front panel. DO NOT OVER FILL.
- Slide the tank back into place and release the lock to automatically secure it.
- Ensure the tank is firmly locked in place.



For additional cooling power, add a couple of ice packs to the water tank before filling with water. Rotate thawed ice packs with frozen ones to keep the water cold. Alternatively you can add ice cubes to the water tank.

Emptying water tank

Unplug the fan from the mains power and carefully remove the water tank. Taking care to take out the pump from inside. Empty the tank and then reinstall it with the pump back inside.

Operating your Fan

Place the fan on a dry, level and sturdy surface.

Check that the fan control switch is set to the off position before plugging into the mains supply.



ON/OFF

- Press ON/OFF button to turn the unit on. The fan will start in normal mode. To turn the unit off, press the button again.

SPEED

- Press the SPEED button to change the fan speed from LOW-MED-HIGH.

COOLING

- Press the COLD button to turn the evaporative cooling effect on and off. The fan will run at the selected speed and blow humidified air into the room.
- NOTE: For COLD mode, the water tank must be filled with water. The water pump must be entirely immersed in the water.
- For added cooling effect, add ice cubes or the ice packs (pre-frozen) to the water tank.

Rotate the ice packs in and out for continued additional cooling.

SWING

- Press the SWING button to turn the oscillating function on and off.

Operating your Fan



MODE

- Press the MODE button to select NORMAL, NATURAL and SLEEP modes.
NORMAL – the fan runs at the selected fan speed
NATURAL – the fan runs in alternating faster and slower speeds and may turn off briefly, to simulate a natural breeze
SLEEP – the fan blows in Natural mode at the selected speed for 30 minutes, then adjusts to the next lower speed for 30 minutes before turning off.



TIMER

- Press the TIMER button until the desired time duration is selected (1-12 hours).
When the set time has elapsed, the fan will turn off.

REMOTE CONTROL

- The buttons on the remote control are exactly the same as on the units control panel.
- Always point the remote control at the fan. Make sure the signal path is not obstructed.
- The remote controls takes 2 x AAA batteries (not supplied).



ICE PACKS



- Add pure clean water to each ice pack to the MAX water level.
- DO NOT EXCEED THE MAX WATER LEVEL OR THE ICE PACK MAY EXPAND AND SPLIT AS THEY FREEZE.
- Freeze the ice pack for 5-6 hours.
- Place the ice packs in the fans water tank.
- Put the packs back in the freezer to refreeze once thawed.


Cleaning and Maintenance

Cleaning the Evaporative Filter

To ensure effective humidifying and filtering, it is recommended that the filtering system be cleaned once every 1-2 weeks.

The Evaporative Filter is located behind the air filter.

1. Unscrew the top of the air filter and remove the air filter.
2. Pull out the cartridge by gently squeezing the top of the cartridge and slowly pull out of the unit.



3. The cartridge should be cleaned by soaking it in warm water with a few drops of mild dish washing detergent.
4. Soak for a few minutes then rinse thoroughly with clean water. Allow the cartridge to fully dry before reinstalling.

Note: Never use appliance without the air filter.

CAUTION: do not immerse or allow the motor or electric cables to come in contact with any liquid.

The fan requires regular cleaning to ensure trouble free operation.

- Ensure that the fan is switched off and unplugged from the supply mains before cleaning.
- Use a vacuum cleaner to remove dust and fluff from around the inlet and outlet grills, alternatively use a damp cloth (not wet) to wipe the exterior of the fan to remove dust and dirt.
- Ensure the fan is dry before plugging back into the mains supply.

Do not attempt to dismantle the fan. There are no user serviceable parts. For service or repair, contact an authorised electrical service technician.



One Year Warranty

Thank you for purchasing this Goldair product. Your product is warranted against faults and manufacture when used in normal domestic use for a period of **one year**.

In non-domestic use Goldair limits the voluntary warranty to **three months**.

Goldair undertake to repair or replace this product at no charge if found to be defective due to a manufacturing fault during the warranty period.

This warranty excludes damage caused by misuse, neglect, shipping accident, incorrect installation, or work carried out by anyone other than a qualified electrical service technician.

The benefits given to you by this warranty are in addition to other rights and remedies available to you under law in relation to the goods or services to which this warranty relates.

In Australia, our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

In New Zealand this warranty is additional to the conditions and guarantees of the Consumers Guarantee Act (1993).

PROOF OF PURCHASE

To receive warranty retain receipt as proof of purchase or register your product (see below).

Register Your Product Here

New Zealand



Goldair – New Zealand

CDB Goldair
PO Box 100-707
N.S.M.C
Auckland, 0745

Phone +64 (0)9 917 4000

Phone 0800 232 633

www.goldair.co.nz

Australia



Goldair – Australia


CDB Goldair Australia Pty
PO Box 574
South Morang
Victoria, 3752

Phone +61 (0)3 9365 5100

Phone 1300 465 324)

www.goldair.com.au

Goldair™



CDB  Goldair™

New Zealand
PO Box 100707,
North Shore Mail Centre,
Auckland, 0745
www.goldair.co.nz

Australia
PO Box 574,
South Morang,
Victoria, 3752
www.goldair.com.au